


INST.No.INE-803

CHINO

Digital Indicating Controller

DB1000

[General]



INSTRUCTIONS

CHINO

Table of Contents

1. INTRODUCTION.....	- 1 -	10. DETAILED EXPLANATION OF MAIN FUNCTIONS.....	- 48 -
2. FOR SAFE USE OF THE PRODUCT.....	- 3 -	10-1 Measurement range	- 48 -
2-1. Prerequisites for use.....	- 3 -	10-2 .Linear scale	- 49 -
2-2. Symbol mark	- 3 -	10-3. Alarm mode.....	- 50 -
2-3. Important	- 4 -	10-4. Execution number and 8 parameters	- 52 -
3. MODEL CODE LIST.....	- 5 -	10-5. Auto tuning.....	- 52 -
4. MOUNTING AND WIRING.....	- 6 -	10-6. PID control.....	- 53 -
4-1. External dimensions.....	- 6 -	10-7. Actuator adjustment of ON-OFF servo type....	- 54 -
4-2. Mounting	- 7 -	10-8. Output 2	- 55 -
4-3. Wiring.....	- 9 -	10-9. Transmission signal output	- 55 -
5. NAME OF VARIOUS PARTS	- 18 -	10-10. Remote signal input	- 56 -
5-1.Entire overview	- 18 -	10-11. External set value switching.....	- 58 -
5-2. Overview of the front panel	- 18 -	10-12. Communication interface.....	- 60 -
5-3. Description of front panel	- 19 -	11. ENGINEERING PORT.....	- 61 -
6. OPERATION SCREEN	- 20 -	12.TROUBLE SHOOTING.....	- 62 -
6-1. Control output and operation screen.....	- 20 -	13. CHECKING AND MAINTENANCE	- 64 -
6-2. Operation screen of output 2 specifications	- 21 -	13-1. Checking.....	- 64 -
6-3. Operation screen and setting screen.....	- 22 -	13-2. Life component	- 64 -
7. SETTING SCREEN	- 23 -	13-3. Disposal	- 64 -
7-1. Basics of setting	- 23 -	14. EXPLANATION OF TERMS.....	- 65 -
7-2. Mode 0 [Settings of parameters that are being executed] ..	- 25 -	15. ACCESSORIES	- 69 -
7-3.Mode 1 [Settings rated to operation status].....	- 26 -	15-1. Front protective cover	- 69 -
7-4. Mode 2 [Settings related to SV]	- 27 -	15-2. Contact protection element	- 69 -
7-5. Mode 3 [Settings related to PID and alarm].....	- 29 -	16. SPECIFICATIONS	- 70 -
7-6. Mode 4 [Settings related to output]	- 31 -	17. PARAMETER LIST.....	- 74 -
7-7. Mode 5 [Settings related to input]	- 34 -	18. PARAMETER DIRECTORY LIST	- 77 -
7-8. Mode 6 [Settings of transmission signal output]	- 36 -		
7-9. Mode 7 [Settings related to communications] ..	- 37 -		
7-10. Mode 11 [Settings related to system].....	- 39 -		
7-11. Initializing the setup parameter.....	- 40 -		
7-12. Precautions while setting	- 40 -		
7-13. Error message	- 41 -		
8. INITIAL SETTINGS.....	- 43 -		
9.OPERATION	- 44 -		
9-1. Confirmations before operation	- 44 -		
9-2. Trial operation	- 44 -		
9-3. Automatic output operation and manual output operation.....	- 46 -		
9-4. Precautions during operation.....	- 47 -		

1. Introduction

Thank you for purchasing Digital Indicating Controller 'DB 1000 series'.

DB 1000 series is Digital Indicating Controller with indicating accuracy of $\pm 0.1\%$, control cycle of approximately 0.1 seconds and front size of 96X96mm.

Universal input and multi SV (8 type) etc. are various functionalities that are provided as standard provisions. Besides a digital indicator with large easy to view LED display, various settings have an interactive system with high resolution dot matrix LCD display and handling is also easy with precise control.

Understand the controller properly and read this instruction manual beforehand in order to avoid any trouble.

This is a 'General' instruction manual. For specification regarding communications, read 'Communication' instruction manual along with this manual.

Request

— **For the persons doing instrumentation, installation and sales** —

Be sure to handover this instruction manual to the persons using the controller.

— **For the users of the controller** —

Preserve this instruction manual until you scrap the controller and write down the setting details.

Notices

1. You should not copy or forward fully or partially this document.
2. The contents of this document may be changed without notice.
3. We have taken enough care regarding the contents of this document however if at all you notice a mistake, contact our nearest office.
4. Please understand that regarding the result of the operation, whatever is the result the company will not be responsible.

■ Before use

After opening the pack, confirm the following before using the product. Although it is rare but if you notice anything wrong, contact your dealer or our nearest office.

1. Confirm the exterior


Confirm that the product is not broken on the outer side.

2. Confirm the model code

Confirm that the model code is that of the model that you purchase.

◆ Model code label and its location

A label as shown below is pasted on the upper surface of the controller unit.



3. Confirm the accessories

The following accessories are attached to the controller, confirm them.

Name	Quantity	Remarks
Mounting bracket	2 (1 set)	For panel mounting
Contact protection element	1	Attached to ON-OFF servo type specifications only
Instruction manual (General)	1	This document
Instruction manual (Communications interface)	1	Attached to communications specifications only (in CD-R)

When accessories are requested separately, sometimes their product is also attached.

Attention

1. Do not drop the instrument while taking it out of the box.
2. When transporting this instrument, pack the instrument in the box and then put it with cushions in another box. We recommend keeping the box for transport.
3. When not using the instrument for a while after taking it from the panel, put the instrument in the box and store at room temperature and in a dust free atmosphere.

2. For safe use of the product

In order to use the controller safely, read the following precautions and understand them.

2-1. Prerequisites for use

The controller is a general product of component type that is used by mounting it in a panel for instrumentation inside a room. Do not use it in any other condition.

When using, design a fail safe on the final product side and review regularly and use the controller after confirming the safety of the system. For the wiring, adjustment and operation of the controller contact a professional having knowledge of instrumentation.

It is necessary that the people actually using this controller read this instruction manual, and have enough understanding of various precautions and the basic operations of the controller.

2-2. Symbol mark

The following symbol marks are used in the product itself and in this instruction manual hence understand the meaning of these symbol marks properly.

Symbol mark	Meaning
 Warning	If there is a possibility of death or severe injuries then explain the precautions to avoid that possibility.
 Caution	If there is a possibility of small injuries or a possibility of the controller or its nearby devices getting damaged then explain the precautions to avoid those possibilities.
	It is a symbol for ground terminal. Always connect the ground terminal to protective grounding.

2-3. Important



Warning

In order to avoid severe accidents always read these contents and understand them.

1. Confirm the power supply and wiring

Before supplying the power to the instrument, check that the wiring is correct, power supply voltage matches with the rated voltage and grounding is done.

2. Over current protection device is installed

The controller does not have a power supply switch. Install an over current protection device (Breaker etc.) that matches the rating specifications, in the power supply of the controller.

3. Protection of terminal

To prevent electric shock, provide the terminal of the controller with safety measures such that the user will not directly be able to touch the final product.

4. Installing the safety device

Regarding the use of a device that anticipates a big loss due to failure of the controller and the peripheral devices, always install a safety device for preventing these losses and implement fail safe design in the final product. Do not use it in important facilities like, human life, atomic energy, aviation and space.

5. Do not put your hands inside the controller

Do not put your hand and tool inside the controller. You may get an injury or an electric shock.

6. Power cut off during suspicion

If there is an offensive smell, a strange noise or smoke or if the temperature increases abnormally, it is very risky hence cut off the power supply immediately and contact the dealer or our nearest office.

7. Prohibiting repairing and remodeling

If repairing or remodeling is necessary, contact the dealer or our nearest office. Only the service engineers appointed by our company will change the parts, do the repairing and remodeling.

8. Strictly follow the instruction manual

In order to use the controller correctly and safely, follow this instruction manual. Please understand beforehand that our company will not at all be responsible for any claims for injury, damage and passive damages due to wrong use of the product.

3. Model code list

D B 1 ④ ⑤ ⑥ B ⑧ ⑨ ⑩ — ⑫ ⑬ ⑭

④ Input signal

- 0: Universal input
- 4: 4-wire resistance thermometer

⑤ Control mode (Output number 1)

- 1: ON-OFF pulse type PID
- 2: ON-OFF servo type PID (Standard load specification)
- 3: Current output type PID
- 5: SSR drive pulse type PID
- 6: Voltage output type PID
- 8: ON-OFF servo type PID (Very little load specifications)

⑥ Control mode (Output number 2)*

- 0: None
- 1: ON-OFF pulse type PID *1
- 3: Current output type PID *1
- 5: SSR drive pulse type PID *1
- 6: Voltage output type PID *1

⑧ Communications interface*

- 0: None
- R: RS232C
- A: RS422A
- S: RS485
- B: External set value switching *2

⑨ Transmission signal output*

- 0: None
- 1: 4-20mA
- 2: 0-1V
- 3: 0-10V
- 4: Other
- B: External set value switching *2

⑩ Remote signal input*

- 0: None
- 5: 4-20mA
- 6: 0-1V
- 7: 0-10V
- 8: Other
- B: External set value switching *2

⑫ Case color

- G: Gray
- B: Black

⑬ IP54 panel sealing specifications and terminal cover*

- 0: None
- 1: Terminal cover
- 2: IP54 panel sealing specifications + No terminal cover
- 3: IP54 panel sealing specifications + Terminal cover

⑭ Power supply voltage

- A: 100-240V (AC)
- D: 24V (AC/DC)

* Option



*1 : Control mode (output number 1) can be selected from 1, 3, 5, 6.

*2 : External set value switching cannot overlap the other zone.

Specified the order of zone3 → zone2 → zone1

4. Mounting and wiring

4-1. External dimensions




Unit: mm

4-2. Mounting

4-2-1. Panel cutout and mounting method


1. Usual mounting method

- ① Insert the controller in panel cutout
- ② Fit in the attached mounting bracket above and below and tighten the screws with the driver and fix it. When the screws are tightened the torque is '0.6 - 0.8 Nm'.
- ③ For IP54 panel sealing specifications, confirm that the gasket between product and panels is correct. Take care because if the gasket drifts or if there is a gap, the mounting is not proper and the water proofing function does not work.



2. Closed instrumentation

- ① Insert the controller in panel cutout.
- ② Fit in the attached mounting bracket above and below and tighten the screws with the driver and fix it. When the screws are tightened the torque is '0.6 - 0.8 Nm'.
- ③ At the time of closed instrumentation, in the product of IP54 panel sealing specifications, as the gasket functionality between the product and the panel is lost, water proofing functionality does not work.



N: Number of mounted instruments

Panel cutout for installation of several controllers

4-2-2. Installation condition



Caution

In order to avoid accidents always read and understand these contents.

1. Environment

- ① In a room.
- ② Away from direct sunlight.
- ③ Away from high temperatures.
- ④ Where there are no vibrations and shocks.
- ⑤ Away from liquids (water etc.).
- ⑥ Away from condensation.
- ⑦ Under 'Excess voltage category II , Pollution level 2'.

2. Atmosphere

- ① Away from strong noise, static electricity, electric field, magnetic field etc.
- ② Surrounding temperature within 10-50°C (Less than 40°C at the time of installing several controllers), surrounding humidity within 10-90% RH.
- ③ Variation in temperature is less.
- ④ Away from corrosive gas, explosive gas, ignition gas and combustible gas.
- ⑤ Away from salt, iron and conductive material (Carbon, iron etc.).
- ⑥ Away from steam, oil and chemicals etc.
- ⑦ Away from dust etc.
- ⑧ Away from the surroundings where high temperature is generated.
- ⑨ Away from places where temperature remains stored.
- ⑩ Product that has a large space on the upper part.
- ⑪ Away from wind.

3. Mounting position

- ① Installation height is 2,000 m above the sea level or less.
- ② Mounting position is approximately 1.5m (Approximately eye level position of a person).
- ③ Mounting orientation longitudinal tilting $\pm 10^\circ$ or less and lateral tilting $\pm 10^\circ$.


4. Other

- ① Do not wipe the controller with an organic solvent (like alcohol).
- ② To avoid malfunctioning of the controller, do not use cell phones in its vicinity.
- ③ An obstacle may be created for television and radio sets placed near the controller.

4-3. Wiring


4-3-1. Terminal number and functionality

Depending on the product specifications, there are also places where terminal screw is not provided.




1. Power supply terminal

① General power supply specifications



② 24V power supply specification



2. Input terminal

Terminal number	Thermocouple Voltage mV	Voltage mV (Range No.35) (Range No.37)	Current mA (Range No.36)	Resistance thermometer (3-wire)	Resistance thermometer (4-wire)
①		⊕	⊕		Ⓐ
②	⊕			Ⓐ	Ⓐ
③	⊖	⊖	⊖	Ⓑ	Ⓑ
④				Ⓑ	Ⓑ
⑤			⊖		

Note) Do not do the wiring only for the specified terminals.

Note) For current mA, short circuit ③ and ⑤.

3. Output terminal

① ON-OFF pulse type

Terminal number	Internal circuit
Output 1	③⑤ N.C. ●
	③⑥ COM. ○
	③⑦ N.O. ○
Output 2	③⑧ N.C. ●
	③⑨ COM. ○
	③⑩ N.O. ○


② ON-OFF servo type

Terminal number	Internal circuit
③⑤	CLOSE
③⑥	OPEN
③⑦	COM.
③⑧	OPEN
③⑨	COM.
③⑩	CLOSE

③ Current output type, SSR drive pulse type, Voltage output type

Terminal number	Current output type	SSR drive pulse type	Voltage output type
Output 1	③⑤	+	+
	③⑥	-	-
	③⑦	/	/
Output 2	③⑧	+	+
	③⑨	-	-
	④⑩	/	/

4. Alarm terminal



Note) Common (COM) terminal is common in AL1/AL2 and Common (COM) terminal is common in AL3/AL4.

5. Option terminal

① Zone 1

Terminal number	Communication RS232C	Communication RS422A	Communication RS485	External set value switching	External set vale switching With external auto/manual switching *Special specifications	External set vale switching With preset manual *Special specifications
⑫	RD	RDA	SA	/	MAN 2 *For output 2 specifications only	/
⑬	SD	RDB	SB	/	MAN 1	PRESET
⑭	SG	SDA	SG	SV 8	SV 8	SV 8
⑮	/	SDB	/	SV 4	SV 4	SV 4
⑯	/	SG	/	SV 2	SV 2	SV 2
⑰	Exclusively for R/L (External signal input)	Exclusively for R/L (External signal input)	Exclusively for R/L (External signal input)	SV 1	SV 1	SV 1
⑱	COM	COM	COM	COM	COM	COM

② Zone 2

Terminal number	Transmission signal output	External set value switching	External set value switching With external auto/manual switching ※Special specifications	External set vale switching With preset manual ※Special specifications
⑱			MAN 2 *For output 2 specifications only	
⑳			MAN 1	PRESET
㉑	⊕	SV 8	SV 8	SV 8
㉒	⊖	SV 4	SV 4	SV 4
㉓		SV 2	SV 2	SV 2
㉔		SV 1	SV 1	SV 1
㉕		COM	COM	COM

③ Zone 3


Terminal number	Remote signal input	External set value switching	External set value switching With external auto/manual switching ※Special specifications	External set vale switching With preset manual ※Special specifications
㉖			MAN 2 *For output 2 specifications only	
㉗	⊕		MAN 1	PRESET
㉘	⊖	SV 8	SV 8	SV 8
㉙		SV 4	SV 4	SV 4
㉚		SV 2	SV 2	SV 2
㉛	Exclusively for R/L (External signal input)	SV 1	SV 1	SV 1
㉜	COM	COM	COM	COM
㉝				
㉞				

4-3-2. Basics of wiring

Precaution	In order to avoid accidents always read and understand these contents.
-------------------	--

1. Connecting to the terminal


- ① For wiring of terminal use crimp style terminal with insulating sleeve. Always use O type terminal to secure safety of power supply terminal and grounding terminal. For other types of terminals also we recommend that you use O type terminal.



- ② When the terminal screws are tightened the torque is '0.6 - 0.8 Nm'. If a torque exceeding this value is applied, terminal screw part gets damaged hence take care.

2. Power supply terminal

- ① In power supply, place the over current protection device and switch that conforms to the ratings of the controller within 3m so that they are easily reachable.



- ② Use a power supply with 600V vinyl insulation electric line (Rating more than 1A AC) and an equal to or greater electric line.
- ③ To avoid malfunctioning use good quality single phase power supply with little voltage change, wave form distortion and noise. If the noise is loud use noise filter and insert insulation transformer etc.
- ④ There is a little leakage of current flow in case or rated power supply hence take care. Leaking current is approximately 1mA. Leakage current go out a little at ground terminal for rated power.

Warning	To avoid serious accidents always cut off the power supply and then do then wiring.
----------------	---

3. Input terminal

- ① Maximum permitted input of input terminal is as follows. Take care of not to applying the input that exceeds these values. If an input that exceeds the range is applied, the product may get out of order or deteriorate remarkably or may malfunction.
 - Thermocouple, voltage mV, voltage V : $\pm 20V$ or less.
 - Resistance thermometer : 500Ω or less, or $\pm 5V$ or less.
 - Current mA : $\pm 30mA$ or less, or $\pm 7.5 m$ or less.
- ② Parallel connection of input is not allowed. Not only measurement error occurs the stable control is not performed and an error occurs in the entire system.
- ③ For thermocouple, do the wiring up to the input terminal of a product by a thermocouple or compensation lead wire.
- ④ To avoid measurement error for resistance thermometer, use cable that resistance value of each line is equal. Take care as burn out is not provided for 4-wire resistance thermometer.
- ⑤ When connecting a protection device like zenner barrier, sometimes a big measurement error may occur. Confirm the combination with protection device and maintain the allowable signal source resistance and allowable wire resistance of the controller.

4. Output terminal

- ① Use an output terminal within the rating range. If a load that is out of range is connected, product may get out of order, its performance may show a remarkable deterioration or it may malfunction.
- ② For relay output terminal of ON-OFF pulse type and ON-OFF servo type connect the load through buffer relay. For contact protection of product internal relay and for noise reduction always insert a contact protection device on the coil side of the buffer relay. In the controller also, a small type of contact protection device is built-in for internal relay protection. Take care because a small leak current flows due to this contact protection device and load voltage.
Leak current is approximately 2mA when load voltage is 200V AC and it is approximately 1mA when load voltage is 100V AC.

5. Alarm terminal

- ① Use the alarm terminal within the rating range. If a load that is out of range is applied, product may get out of order, its performance may show a remarkable deterioration or it may malfunction.
- ② For alarm terminal always connect the load through buffer relay. For contact protection of product internal relay and for noise reduction always insert a contact protection device on the coil side of the buffer relay.

6. Option terminal

- ① Use the option terminal within the rating range. If a load that is out of range is applied, product may get out of order, its performance may show a remarkable deterioration or it may malfunction.


Precaution

- ① If a power supply that is out of range is connected, product may get out of order, its performance may show a remarkable deterioration or it may malfunction.
- ② If an excess current or excess voltage is applied to input output of the controller product may get out of order, its performance may show a remarkable deterioration or it may malfunction.

4-3-3. Example of wiring

1. ON-OFF servo type wiring

ON-OFF servo type is connected with a motor. Refer to the terminal diagram of the motor that uses three terminals of control relay output and three terminals of feedback input and do the wiring.



In the above diagram, the controller and control motor manufactured by our company are directly connected however, while actually connecting always insert a buffer relay and then connect. Furthermore, always connect a contact protection device in control relay output terminal.

The contact protection device attached to the controller is for the motor (For load current 700 mA and above).


When connecting with the use a contact protection device for light load. If contact protection device of the attachment is used in buffer relay, operation defect occurs due to leakage current.

For you reference symbolic name list of motors of various companies is given below.

Symbolic name list of motors of various companies				
Chino Products	Toho Products	Shin-Nippon Keisetsu Products	Japan Servo Products	Yamatake Products
M 3	S	S	T 2	1
M 2	O	O	T 1	2
M 1	C	C	T 3	3
R 1	BM	B	B	Y
R C	RM	R	R	T
R 2	WM	W	W	G

2. Relay output wiring example


In relay outputs like ON-OFF pulse type, ON-OFF servo type and alarm output, always connect through buffer relay and contact protection device.



Contact protection device is handled in our company also (See 15. Accessories).

When power supply is an AC power supply, CR compound device, and when it is a direct current, diode is generally used.

3. Wiring example of External set value switching



In the figure on the left approximately 5V and 2mA is applied. Take care about the contact quantity.

Execution NO. selection that depends on external signal input, operates by short circuiting the specified External set value switching terminal and common (COM) terminal. Operating by using a switch and relay is a general method however, operation can be performed by using open corrector signal of peripheral device.

4-3-4. Precautions while wiring



In order to avoid accidents always read and understand these contents.

1. Wiring is done by professional

Wiring is to be done by a person having actual experience and basic knowledge of instrumentation.

2. Put the terminal cover

In order to ensure safety, after the wiring is done, take measures so as to prevent direct contact with the terminal of the product.

Exclusive terminal cover of the controller is available as accessory (Sold separately).

3. Keep away from strong electric circuit and from noise source

In order to prevent bad effect due to noise, do not place the controller near a device from which noise is generated (magnet relay, motor, thyristor regulator, inverter etc.). Also avoid passing the wiring of the controller and that of noise generating devices through the same duct. Always keep the wiring away from each other. Take the necessary countermeasures against noise.

4. Careful about connecting ground terminal

Good grounding is important for reliability of the instrument. In most cases, it is better that each instrument is connected at a point. When connected separately, it is easy to get a bad effect due to noise. Check the connecting route.

5. Keep away from heat generating sources

In order to avoid bad effect due to high temperature, do not install the controller near heat generating sources. If the controller is kept near any heat generating source, measurement goes wrong and finally the life of the product is shortened. Take care about the surrounding temperature of the product.

Avoid places where there is wind and sudden temperature change, it also causes an error in measurement. Take necessary measures to avoid such surrounding environment.

6. Unused terminal


Do not connect anything to the unused terminal. Product may get out of order.

7. Countermeasures against erroneous output when power is supplied

When power is supplied, sometimes the output related signal may be momentarily output when the controller is starting normally. Take the necessary countermeasures by using an external circuit.


5. Name of various parts

5-1. Entire overview



5-2. Overview of the front panel


⚠ Precaution
 This internal rack fixing screw is used at the time of maintenance. Customers please do not touch it.



Name	Function
Upper display window	Displays PV, SV and various statuses.
Lower display window	Displays operation screen and settings screen.
Key switch panel	It is used for various settings. When power is supplied or any of the key is pressed key back light (blue) lights (At the time of initial settings). When no operation is done for about 30 seconds or more, the back light goes off automatically. This back light is illuminated till the end and brightness is uneven hence the blue color has a bright part.. However it does not hinder the functionality of the product hence use it as it is.
Engineering port	Settings from PC can be done after connecting the exclusive engineering cable.
Lower cover	When using engineering port open the lower cover. AT other times keep it closed tightly.

5-3. Description of front panel

5-3-1. Upper display window



Name	Function
P V	Displays PV (measurement value).
S V	Displays SV (setting value).
N O .	Displays the execution number that is being selected.
R U N	Lights during operating status.
S L O P E	Lights during slope operation of SV.
W A I T	Lights when alarm output is released (reset). Lights when wait during the wait alarm.
R E M	Lights during remote status.
E R R	Lights when there is an abnormality in taking in the input.
A T	Lights during auto tuning operation.
M A N 1	Lights when output 1 is a manual output operation.
M A N 2	Lights when output 2 is a manual output operation.
A L 1 - A L 4	Lights when alarm from AL1 to AL4 is ON.

5-3-2. Key switch panel



Name	Function
MODE	It is used for changing of mode screens like operation screen and mode 0 and conversion from settings screen to mode screen.
SEL	It is used for changing the operation screen and conversion of settings screen.
A/M	It is used for changing between automatic output operation and manual output operation. This switch can be use for rewinding the cursor at setting screen.
>	It is used for sending the cursor and for selecting a field.
V	It is used for descending order of settings value (or settings field).
^	It is used for ascending order of settings value (or settings field).
ENT	It is used for registering the settings.

6. Operation screen

6-1. Control output and operation screen

Lower display window displays operation screen and settings screen. However the display contents of operation screen differ depending on the control output of the product.

Control output and operation screen	Description of screen
<p>[ON-OFF pulse type] [SSR DRIVE PULSE TYPE]</p>  <p>※The above is a mock display. Actually OFF and ON do not light simultaneously.</p>	<ul style="list-style-type: none"> ① ON lights when output status is ON and OFF lights when output status is OFF. ② Displays MV (output value) digitally. ③ At the time of manual output operation (manual output) 'M' on the left of 'OUT' lights. ④ During PID auto tuning, 'AT' on the left of 'OUT' lights.
<p>[Current output type] [Voltage output type]</p> 	<ul style="list-style-type: none"> ① Displays a bar graph corresponding to the output value. ② Displays MV (output value) digitally. ③ At the time of manual output operation (manual output) 'M' gets lit on the left of 'OUT'. ④ During PID auto tuning, 'AT' gets lit on the left of 'OUT'.
<p>[ON-OFF servo type]</p>  <p>※The above is a mock display. Actually CLOSE and OPEN do not light simultaneously.</p>	<ul style="list-style-type: none"> ① When signal on the close side is ON CLOSE lights and when signal on the open side is ON OPEN lights. When both the signals are OFF both CLOSE and OPEN do not light. ③ Displays feedback value (extent of valve opening) digitally. ④ At the time of manual output operation (manual output) 'M' gets lit on the left of 'OUT'. ⑤ During PID auto tuning, 'AT' gets lit on the left of 'OUT'. ⑥ During FB tuning, 'AT' gets lit on the left of 'FB'.


6-2. Operation screen of output 2 specifications

For output 2 specifications, unlike normal output 1 specifications, operation screen is displayed for each output.

Operation screen for output 1	Operation screen for output 2
<p>[ON-OFF pulse type] [SSR DRIVE PULSE TYPE]</p> 	<p>[ON-OFF pulse type] [SSR DRIVE PULSE TYPE]</p> 
<p>[Current output type] [Voltage output type]</p> 	<p>[Current output type] [Voltage output type]</p> 
<p>① Operation screen of output 1 becomes 'OUT1' after adding '1' on the right of 'OUT' and thus indicates that it is an operation screen for output 1. Similarly, operation screen of output 2 becomes 'OUT2' after adding '2' on the right of 'OUT' and thus indicates that it is an operation screen for output 2.</p> <p>② Switch the output 1 operation screen and output 2 operation screen by using  key.</p>	

6-3. Operation screen and setting screen

Relation between operation screen and settings screen is as follows.




7. Setting screen

7-1. Basics of setting

7-1-1. Call up the setting screen

- ① Setting screen is grouped for every mode as mentioned in '1.8 Parameter directory list table'. Confirm number and the mode of the settings screen that is to be called up.
- ② Switching between operation screen and mode screen is done by **MODE** key, mode screen is selected by **▲** · **▼** key and setting screen is selected by using **SEL** key from mode screen respectively.



7-1-2. Basic operation of settings screen

In the settings screen, numeric value is changed and field is selected by using \triangleright · \triangle · ∇ key and settings are completed by clicking ENT key.

Example of basic operation	
<p>1. Example of setting a numeric value</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> P I D No. 1 P : <u>0</u> 0 5 . 0 % I : 0 0 6 0 s D : 0 0 3 0 s </div>	<p>① By using \triangleright key the cursor is moved to the digit of the numeric value that is to be changed.</p> <p>② By using \triangle · ∇ key the desired numeric value is selected. '?' mark is put.</p> <p>③ The value is registered by using the ENT key. '?' mark disappears.</p>
<p>2. Example (1) of setting a field</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> INPUT KIND 0 5 <u>K</u> 1 </div>	<p>① By using \triangle · ∇ key the desired field is selected. '?' mark is put.</p> <p>② The field is registered by using the ENT key. '?' mark disappears.</p>
<p>3. Example (2) of setting a field</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> MEASURE UNIT ° <u>C</u> K </div>	<p>① By using \triangleright key the desired field is selected. '?' mark is put.</p> <p>② The field is registered by using the ENT key. '?' mark disappears.</p>

A convenient key operation method is given below in order to speed up the settings operation.

<p>1. Fast forwarding the cursor</p> <p>① Usually, cursor moves by one digit by using \triangleright key, however by using the ENT key, the cursor can be moved by, set field unit.</p> <p>② For example in the following PID settings screen, when ENT key is clicked, the cursor moves as shown below.</p> <div style="text-align: center; margin: 20px 0;"> <p>'No.'</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px;"> P I D No. <u>1</u> P : 0 0 5 . 0 % I : 0 0 6 0 s D : 0 0 3 0 s </div> <div style="font-size: 2em;">→</div> <div style="border: 1px solid black; padding: 5px;"> P I D No. 1 P : 0 0 <u>5</u> . 0 % I : 0 0 6 0 s D : 0 0 3 0 s </div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;"> <p>↑ ENT</p> <p>'Left most digit of the numeric value that is set, of D'</p> <div style="border: 1px solid black; padding: 5px;"> P I D No. 1 P : 0 0 5 . 0 % I : 0 0 6 0 s D : 0 0 <u>3</u> 0 s </div> </div> <div style="text-align: center;"> <p>↓ ENT</p> <p>'Left most digit of the numeric value that is set, of I'</p> <div style="border: 1px solid black; padding: 5px;"> P I D No. 1 P : 0 0 5 . 0 % I : 0 0 <u>6</u> 0 s D : 0 0 3 0 s </div> </div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;"> <p>← ENT</p> </div> </div> </div>
<p>2. Rewinding the cursor</p> <p>Usually by using the \triangleright key, the cursor moves by one digit from left to right, however by clicking the \triangleleft key, the cursor can be moved from right to left.</p>





7-2. Mode 0

Mode 0 changes the setting of main parameters that are being executed.

Settings screen	Description of the screen
<p>1. Mode screen</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> MODE 0 RUN PARAMETER </div> <p>[Lock status]</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> MODE 0 Lock RUN PARAMETER </div> <p>[Display off status]</p> <div style="border: 1px solid black; padding: 5px;"> MODE 0 NoDisp RUN PARAMETER </div>	<p>① Mode 0 screen.</p> <p>② By clicking the  key, 'Lock' and 'NoDisp' is displayed.</p> <p>③ For mode 0 settings screen, if setting change is to be prohibited select 'Lock' .</p> <p>④ When doing the settings by communications, set all the mode screens to 'Lock' .</p> <p>⑤ When settings screen of mode 0 is not displayed, 'NoDisp' is displayed.</p>
<p>2. SV being executed</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> SET VALUE No. 1 0 0 0 0 . 0 </div>	<p>① SV that is being executed can be changed.</p> <p>② Setting range is within the measured range (include linear scale).</p> <p>③ The change in the settings of this screen, is reflected in the set contents of '8 types SV' of mode 2.</p>
<p>3. PID being executed</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> PID No. 1 P : 0 0 5 . 0 % I : 0 0 6 0 s D : 0 0 3 0 s </div>	<p>① PID that is being executed can be changed.</p> <p>② The change in the settings of this screen, is reflected in the set contents of '8 types PID' of mode 3.</p>
<p>4. Alarm 1 and Alarm 2 that are being executed</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> ALARM AL1/AL2 No. 1 3 0 0 0 . 0 / - 1 9 9 9 . 9 </div>	<p>① The set values of alarm 1 and alarm 2 that are being executed can be changed.</p> <p>② The change in the settings of this screen, is reflected in the set contents of 'Alarm 1 and Alarm 2' of mode 3.</p>
<p>5. Alarm 3 and Alarm 4 that are being executed</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> ALARM AL3/AL4 No. 1 3 0 0 0 . 0 / - 1 9 9 9 . 9 </div>	<p>① The set values of alarm 3 and alarm 4 that are being executed can be changed.</p> <p>② The change in the settings of this screen, is reflected in the set contents of 'Alarm 3 and Alarm 4' of mode 3.</p>

7-3.Mode 1

Mode 1 performs the setting related to operation status.

Settings screen	Description of the screen
<p>1. Mode screen</p>  <p>[Lock status]</p>  <p>[Display off status]</p> 	<p>① Mode 1 screen.</p> <p>② By clicking the  key, 'Lock' and 'NoDisp' is displayed.</p> <p>③ For mode 1 settings screen, if setting change is to be prohibited select 'Lock'.</p> <p>④ When doing the settings by communications, set all the mode screens to 'Lock'.</p> <p>⑤ When settings screen of mode 1 is not displayed, 'NoDisp' is displayed.</p>
<p>2. Cancel alarm output</p> 	<p>① When canceling temporarily the alarm output that is activated, alarm output is cancelled when 'RESET' is set.</p> <p>② At that time the cursor immediately returns to 'NON' and 'WAIT' of upper display window lights.</p> <p>③ In cancel (WAIT) status, once the you move from alarm activation condition, 'WAIT' lights and normal status returns.</p> <p>④ Take care as the settings are common for alarm output of all the 4 points.</p>
<p>3. Switching between remote/local</p> 	<p>① This screen is displayed if the instrument has the specifications with remote signal input or specifications with communication.</p> <p>② Local SV and remote SV can be switched.</p> <p>③ When 'LOCAL' is selected, perform the control operation in local SV.</p> <p>④ When 'REMOTE' is selected, you can perform control operation in remote SV by using external remote signal (analog remote or digital remote).</p> <p>⑤ 'REMOTE' is selected in this setting screen and only when external signal input (R/L) is ON, it becomes remote SV.</p>
<p>4. Selecting execution no.</p> 	<p>① From amongst 8 types SV, execution no. of the one to be used is set.</p> <p>② The selected number is displayed on the left side of SV in the upper display window.</p> <p>③ When execution number is selected in External set value switching, the selection number due to External set value switching is given priority and not the setting value of this setting screen.</p>

<p>5. Auto tuning</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> PID AUTO TUNING END START </div>	<ul style="list-style-type: none"> ① Auto tuning (auto calculation) of PID is done. ② When auto tuning is started, AT progress status (STEP1-STEP4)report is displayed. ③ If you want to stop auto tuning in between, set 'END'. ④ PID calculated by auto tuning can be confirmed by setting screen of each PID.
<p>6. Selecting single function/multiple functions</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> OPERATE MODE SIMPLE MULTI </div>	<ul style="list-style-type: none"> ① Switching between single function and multiple functions can be done. ② If 'SIMPLE' is selected, it is a single function mode and setting screen of mode 2 and above are not displayed. ③ If 'MULTI' is selected, it is a multiple function mode and setting screens of all the modes is displayed.

7-4. Mode 2

Mode 2 performs the setting related to SV.

Settings screen	Description of the screen
<p>1. Mode screen</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> MODE 2 SET VALUE </div> <p>[Lock status]</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> MODE 2 Lock SET VALUE </div> <p>[Display OFF status]</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> MODE 2 NoDisp SET VALUE </div>	<ul style="list-style-type: none"> ① Mode 2 screen ② By clicking the key, 'Lock' and 'No Disp' is displayed. ③ For mode 2 settings screen, if setting change is to be prohibited select 'Lock'. ④ When doing the settings by communications, set all the mode screens to 'Lock'. ⑤ When settings screen of mode 2 is not displayed, select 'NoDisp'.
<p>2. 8 types SV</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> SET VALUE No. 1 0 0 0 0 . 0 </div>	<ul style="list-style-type: none"> ① Set 8 types of SV. ② Number 1 to 8 corresponds to execution number 1-8. ③ Setting range is the measured range (include linear scale) within the SV range. ④ When measurement range, unit, linear scale etc is changed, setting range and decimal point position may change automatically hence take care.

<p>3. SV change rate</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> SV UP: 0000.0 SLP DW: 0000.0 / M </div>	<ol style="list-style-type: none"> ① When SV is changed, slope operation can be stored in SV. ② Upward change rate (for every unit time) of SV is set in 'UP' and downward change rate (for every unit time) of SV is stored in 'DW'. Time unit is common for 'UP' and 'DW', and can be selected from 'H': hours, 'M': minutes, 'S': seconds. ③ Conditions for SV change rate to be valid are as follows. <ul style="list-style-type: none"> ▪ At the time of power supply. ▪ When set value of SV is changed during execution. ▪ When the execution number is changed. ▪ When it switched from manual output operation to automatic output operation. ▪ When it switched from remote SV to local SV. <ul style="list-style-type: none"> ※ However when switch local SV to remote SV, SV change rate doesn't work. ④ When returning from power failure or switching from manual output operation to automatic output operation, it becomes PV start operation. ⑤ During slope operation, sloping SV is displayed in upper display window and 'SLOPE' lights, indicating that slope operation is being performed. ⑥ When SV change rate is to be disabled, set UP and DW as '0'. ⑦ When measurement range, unit, linear scale etc is changed, setting range and decimal point position may change automatically hence take care.
<p>4. Remote scale</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> REMOTE SCALE -0200.0 ~ 1370.0 </div>	<ol style="list-style-type: none"> ① Specifications with remote signal input is only displayed. ② Set the scale corresponding to remote signal input (analog signal). ③ Set the upper limit of the scale whose lower limit is (0%) and whose upper limit is (100%) to (100%). ④ When measurement range, unit, linear scale etc is changed, setting range and decimal point position may change or it may be initialized hence take care.
<p>5. Remote shift</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> REMOTE SHIFT 000.00 </div>	<ol style="list-style-type: none"> ① This screen is displayed if the instrument has the specifications with remote signal input or specifications with communications. ② Shift (Bias) value of remote is set. ③ When measurement range, unit, linear scale etc is changed, decimal point position may change automatically hence take care.
<p>6. Remote filter</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> REMOTE FILTER 00.0s </div>	<ol style="list-style-type: none"> ① This screen is displayed if the instrument has the specifications with remote signal input or specifications with communications. ② First-order lag operation is done in remote SV. This function is enabled when flat key in external remote signal input (analog signal) is large.
<p>7. Cascade constant</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> CASCADE r: 1.00 b: 000.0% </div>	<ol style="list-style-type: none"> ① Specifications with remote signal input is only displayed. ② This function is used when performing cascade operation as secondary regulator of cascade control loop. ③ Ratio is set in 'r' and bias is set in 'b'.

7-5. Mode 3

Mode 3 performs the setting related to PID and alarm.

Settings screen	Description of the screen
<p>1. Mode screen</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> MODE 3 PID / ALARM </div> <p>[Lock status]</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> MODE 3 Lock PID / ALARM </div> <p>[Display OFF status]</p> <div style="border: 1px solid black; padding: 5px;"> MODE 3 NoDisp PID / ALARM </div>	<p>① Mode 3 screen.</p> <p>② By clicking the  key, 'Lock' and 'NoDisp' is displayed.</p> <p>③ For mode 3 settings screen, if setting change is to be prohibited select 'Lock'.</p> <p>④ When doing the settings by communications, set all the mode screens to 'Lock'.</p> <p>⑤ When settings screen of mode 3 is not displayed, select 'NoDisp'.</p>
<p>2. 8 types PID</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> PID No.1 P: 005.0% I: 0060s D: 0030s </div>	<p>① Set all 8 types of PID from number 1 to 8.</p> <p>② Numbers 1 to 8 correspond to execution numbers 1 to 8.</p> <p>③ By setting P as 0%, two-position control operates.</p> <p>④ When I is set in 0s, it is equivalent to ∞. When D is set in 0s, it is equivalent to OFF.</p>
<p>3. Output dead band</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> P=0 D.BAND 0.5% </div>	<p>① Set output dead band.</p> <p>② Set output dead band of two-position control operation (When P=0%).</p> <p>③ Output dead band of two-position control operation becomes the dead band at the time of output ON/OFF.</p>
<p>4. Output 2 PID</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> OUT2 PID P: 005.0% I: 0060s D: 0030s </div>	<p>① This screen is displayed only with output 2 specification.</p> <p>② Set PID for output 2.</p>
<p>5. Output 2 gap</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> OUT1-OUT2 GAP 000.0% </div>	<p>① This screen is displayed only with output 2 specification.</p> <p>② Gap between output1 and output 2 is set.</p>

<p>6. Output 2 dead band</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>P = 0 D . B A N D 0 . 5 %</p> </div>	<ol style="list-style-type: none"> ① This screen is displayed only with the output 2 specification. ② Set output dead band for output 2. ③ Set output dead band of two-position control operation (When P=0%). ④ Output dead band of two-position control operation becomes a dead band at the time of output ON/OFF.
<p>7. Alarm 1 and Alarm 2</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>A L A R M A L 1 / A L 2 No. 1 3 0 0 0 . 0 / - 1 9 9 9 . 9</p> </div>	<ol style="list-style-type: none"> ① Set 8 types of settings values of alarm 1 and alarm 2. ② Numbers 1 to 8 correspond to execution numbers 1 to 8. ③ When measurement range, unit, linear scale, alarm form etc is changed, setting range and decimal point position may change automatically hence take care.
<p>8. Alarm 3 and Alarm 4</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>A L A R M A L 3 / A L 4 No. 1 3 0 0 0 . 0 / - 1 9 9 9 . 9</p> </div>	<ol style="list-style-type: none"> ① Set 8 types of settings values of alarm 3 and alarm 4. ② Numbers 1 to 8 correspond to execution numbers 1 to 8. ③ When measurement range, unit, linear scale, alarm format etc is changed, setting range and decimal point position may change hence take care.
<p>9. Alarm format</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>A L A R M 1 : D H 2 : D L M O D E 3 : D H 4 : D L</p> </div>	<ol style="list-style-type: none"> ① Set the alarm format of alarm 1-4 (AL1-AL4). ② There are 8 types of alarm forms as shown below. Set the respective types for AL1-AL4. <ul style="list-style-type: none"> • DH : Deviation higher limit alarm • DHW : Waiting deviation higher limit alarm • DL : Deviation lower limit alarm • DLW : Waiting deviation lower limit alarm • AH : Absolute value higher limit alarm • AHW : Waiting absolute value higher limit alarm • AL : Absolute value lower limit alarm • ALW : Waiting absolute value lower limit alarm
<p>10. Alarm dead band</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>A L A R M D . B A N D A L 1 0 0 2 . 0 0</p> </div>	<ol style="list-style-type: none"> ① Set alarm dead band of alarm 1 to 4. ② Unit is same as the setting value of respective alarm. ③ When measurement range, unit, linear scale, alarm form etc is changed, setting range and decimal point position may change automatically hence take care.
<p>11. A.R.W</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>A . R . W . L - 0 5 0 . 0 % H 0 5 0 . 0 %</p> </div>	<ol style="list-style-type: none"> ① Set ARW (Anti Reset Windup). ② It is a function for deciding the range of PID operation , for PID control. If this set value is exceeded it becomes a PD operation. ③ Setting value is % of measurement range (include linear scale). ④ This setting is operated only at the position type PID mode.

<p>12. Control algorithm</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">PID TYPE POSITION/VELOCITY</p> </div>	<p>① Set control algorithm. ② If 'POSITION' is selected, it is position type PID mode. ③ If 'VELOCITY' is selected, it is velocity type PID mode.</p>
---	---

7-6. Mode 4

Mode 4 performs the setting related to output.

Settings screen	Description of the screen
<p>1. Mode screen</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">MODE 4 OUTPUT SET</p> </div> <p>[Lock Status]</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">MODE 4 Lock OUTPUT SET</p> </div> <p>[Display OFF status]</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">MODE 4 NoDisp OUTPUT SET</p> </div>	<p>① Mode 4 screen. ② By clicking the key, 'Lock' and 'No Disp' is displayed. ③ For mode 4 settings screen, if setting change is to be prohibited select 'Lock'. ④ When doing the settings by communications, set all the mode screens to 'Lock'. ⑤ When settings screen of mode 4 is not displayed, select 'NoDisp'.</p>
<p>2. Pulse cycle</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">PULSE CYCLE 0 3 0 s</p> </div> <p>[Output 2 specifications]</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">PULSE CYCLE OUT1/2 0 3 0 s / 0 3 0 s</p> </div>	<p>① Only ON-OFF pulse type or SSR drive pulse type is displayed. ② Set time for one cycle of output ON/OFF. ③ In output 2 specifications, for pulse type also set output 2 respectively. ④ When set value is changed, after ending a cycle just before the setting change, perform the operation with the settings value after the setting change. ⑤ Generally, set it in a range that does not adversely affect the controllability and set a bigger value as far as possible.</p>
<p>3. FB tuning</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%;"> <p style="text-align: center;">F. B. AUTO TUNING END START</p> </div>	<p>① ON-OFF servo type only is displayed. ② It is a function that automatically requests a setting value of FB zero span of the controller with actuator (motor etc.). ③ When FB tuning is started, AT progress status (START, CLOSE, TUNE-ZERO, OPEN, TUNE-SPAN) is displayed. ④ If FB tuning is to be stopped in between, set 'END'. ⑤ FB zero span requested at the time of FB tuning can be confirmed by 'FB zero span' of mode 4.</p>

<p>4. FB zero span</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>F. B. ZERO / SPAN Z : 00.0% S : 100.0%</p> </div>	<ul style="list-style-type: none"> ① ON-OFF servo type only is displayed. ② Set FB zero span of the controller with actuator (motor etc). ③ Set zero value in 'Z' and span value in 'S'.
<p>5. FB dead band</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>F. B. D. BAND 1.0%</p> </div>	<ul style="list-style-type: none"> ① ON-OFF servo type only is displayed. ② Set FB dead band (Gain). ③ Generally, set it in a range that does not adversely affect the controllability and set a bigger value as far as possible. This setting value is not an accurate percentage (%) value, hence as far as possible take it as a reference.
<p>6. Output during PV abnormality</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>PV ERR OVR : 000.0% OUT UDR : 000.0%</p> </div>	<ul style="list-style-type: none"> ① Set the output value at the time of PV abnormality. ② Set the output value in 'OVR' when PV exceeds the range (including upper limit burnout) and in 'UDR' when PV is below the range (including lower limit burnout) respectively. ③ Output range is within the output limiter range. ④ In case of output 2 specifications, this value is enabled only on output 1 side and on output 2 side the output value is 0% at all times.
<p>7. Output preset</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>OUTPUT PRESET 050.0%</p> </div>	<ul style="list-style-type: none"> ① Set output preset. ② Output range is within the range of output delimiter. ③ In case of output 2 specifications, this value is enabled only on output 1 side and on output 2 is 0% fixation.
<p>8. Output change quantity limiter 8 types</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>OSL UP/DOWN No. 1 100.0% / -100.0%</p> </div>	<ul style="list-style-type: none"> ① Set 8 types of output change quantity limiters. ② Numbers 1 to 8 correspond to execution numbers 1 to 8. ③ On the lower left set output change quantity limiter at the time of ascending output and on the lower right set output change quantity limiter at the time of descending output. <p>* For specifications with external input for switching over the set value and specifications with preset manual (option) display up to No. 9. Then set the variation limiter of MV (output value) when switching to output preset operation from automatic output operation by using No. 9.</p>

<p>9. Output limiter 8 types</p> <pre> OUTPUT LIMIT No. 1 L: 000.0% H: 100.0% </pre> <p>[Output scale specifications]</p> <pre> OUTPUT SCALE No. 1 L: 000.0% H: 100.0% </pre> <p>※ Option</p>	<ol style="list-style-type: none"> ① Set 8 types of output limiters. ② Numbers 1 to 8 correspond to execution numbers 1 to 8. ③ Set lower limit output limiter in 'L' and higher limit output limiter in 'H'. ④ Output is within this set range in any of automatic output operation and manual output operation. ⑤ For output scale specifications (option) instead of output limiter, the screen is as shown on the left below.
<p>10. Output 2 limiter</p> <pre> OUT2 OUTPUT LIMIT L: 000.0% H: 100.0% </pre> <p>[Output scale specifications]</p> <pre> OUT2 OUTPUT SCALE L: 000.0% H: 100.0% </pre> <p>※ Option</p>	<ol style="list-style-type: none"> ① Only output 2 specifications are displayed. ② Set the output limiter on output 2 side. ③ Set lower limit output limiter in 'L' and higher limit output limiter in 'H'. ④ Output is within this set range in any of automatic output operation and manual output operation. ⑤ For output scale specifications (Special specifications) instead of output limiter, the screen is as shown on the left below.
<p>11. Direct/reverse control operation</p> <pre> OUTPUT MODE DIRECT REVERSE </pre> <p>[Output specifications]</p> <pre> OUTPUT MODE OUT1/2 REVERSE / DIRECT </pre>	<ol style="list-style-type: none"> ① Set the control operation. ② If 'DIRECT' is selected direct operation (cooling operation) is done. ③ If 'REVERSE' is selected reverse operation (heating operation) is done. ④ For output 2 specifications, see the screen on lower left, on the left of '/' is the control operation of output 1 and on the right is the control operation of output 2. Set each of them separately.
<p>12. Preset manual</p> <pre> PRESET MANUAL OUT 000.0% </pre> <p>※ Option</p> <p>[Output specifications]</p> <pre> PRESET MANU OUT1/2 000.0% / 000.0% </pre> <p>※ Option</p>	<ol style="list-style-type: none"> ① It is not displayed in usual specifications. It is displayed only in specifications with External set value switching and specifications with preset manual (option). ② Set the preset manual. ③ When preset manual is ON due to external signal input, output value is the set value. ④ Output range is within the range of output limiters. ⑤ For output scale specifications the screen is as shown on the left below, set each of the field separately.

7-7. Mode 5

Mode 5 performs the setting related to input.

Settings screen		Description of the screen									
1. Mode screen  [Lock Status]  [Display OFF status] 		① Mode 5 screen. ② By clicking the \boxtimes key, 'Lock' and 'No Disp' is displayed. ③ For mode 5 settings screen, if setting change is to be prohibited select 'Lock'. ④ When doing the settings by communications, set all the mode screens to 'Lock'. ⑤ When settings screen of mode 5 is not displayed, select 'NoDisp'.									
2. Measurement range 		① Set the measurement range. ② Types of measurement ranges are as shown in the table below. ③ It differs depending on the measurement range, however it exceeds the upper limit of the scale range by approximately +5% and is below the range by approximately -5%. ④ When measurement range is changed, setting range and decimal point position may change or initialization may take place automatically hence take care.									
[Universal]											
No.	Measurement range	Scale range (°C)	No.	Measurement range	Scale range (°C)	No.	Measurement range	Scale range (°C)			
01	Thermocouple	B	0.0 to 1820.0	18	Thermocouple	WRe5-26	0.0 to 2310.0	36	DC (Linear)	20mA	0 to 20mA
02		R1	0.0 to 1760.0	19		W-WRe26	0.0 to 2310.0				
03		R2	0.0 to 1200.0	20		NiMo-Ni	-50.0 to 1410.0				
04		S	0.0 to 1760.0	21		CR-AuFe	0.0 to 280.0 K	41	Resistance thermometer	JPt100Q1	-200.0 to 649.0
05		K1	-200.0 to 1370.0	22		N	0.0 to 1300.0	42		JPt100Q2	-200.0 to 400.0
06		K2	0.0 to 600.0	23		PR5-20	0.0 to 1800.0	44		JPt100Q4	-200.0 to 200.0
07		K3	-200.0 to 300.0	24		PtRh40-20	0.0 to 1880.0	45		JPt100Q5	-100.0 to 100.0
08		E1	-270.0 to 1000.0	25		Plati II 1	0.0 to 1390.0	46		QPt100Q1	-200.0 to 649.0
09		E2	0.0 to 700.0	26		Plati II 2	0.0 to 600.0	47		QPt100Q2	-200.0 to 400.0
10		E3	-270.0 to 300.0	27		U	-200.0 to 400.0	49		QPt100Q4	-200.0 to 200.0
11		E4	-270.0 to 150.0	28	L	-200.0 to 900.0	50	QPt100Q5		-100.0 to 100.0	
12		J1	-200.0 to 1200.0	31	DC voltage (Linear)	10mV	±10mV	51		JPt50Q	-200.0 to 649.0
13		J2	-200.0 to 900.0	32		20mV	±20mV	53		Pt100Q1	-200.0 to 850.0
14		J3	-200.0 to 400.0	33		50mV	±50mV	54	Pt100Q2	-200.0 to 400.0	
15		J4	-100.0 to 200.0	34		100mV	±100mV	56	Pt100Q4	-200.0 to 200.0	
16		T1	-270.0 to 400.0	35		5V	±5V	57	Pt100Q5	-100.0 to 100.0	
17		T2	-200.0 to 200.0	37		10V	±10V				

[4-wire resistance thermometer]

No.	Measurement range	Scale range (°C)	No.	Measurement range	Scale range (°C)	No.	Measurement range	Scale range (°C)
41	JPt100Ω1	-200.0 to 649.0	47	QPt100Ω2	-200.0 to 400.0	53	Pt100Ω1	-200.0 to 850.0
42	JPt100Ω2	-200.0 to 400.0	49	QPt100Ω4	-200.0 to 200.0	54	Pt100Ω2	-200.0 to 400.0
44	JPt100Ω4	-200.0 to 200.0	50	QPt100Ω5	-100.0 to 100.0	56	Pt100Ω4	-200.0 to 200.0
45	JPt100Ω5	-100.0 to 100.0	51	JPt50Ω	-200.0 to 649.0	57	Pt100Ω5	-100.0 to 100.0
46	QPt100Ω1	-200.0 to 649.0	52	Pt-Co	4.0 to 374.0K			

3. Unit

MEASURE UNIT
° C K

- ① Set the unit when measured range is “thermocouple” or “resistance thermometer”.
- ② When measurement range is 'CR-AuFe' or 'Pt-Co' unit is 'K' only and '°C' can be not selected.
- ③ When unit is changed, setting range and decimal point position may change or initialization may take place automatically hence take care.

4. RJ

RJ CALCULATION
INT EXT

- ① This screen is displayed only selected “thermocouple” at measured range.
- ② When 'INT' is selected RJ functionality is switched ON. Usually 'INT' is selected.
- ③ When 'EXT' is selected RJ functionality is switched OFF.

5. Digital filter

PV FILTER
00.1 s

- ① Do the first-order lag operation in PV. It is a valid function when PV is unstable.

6. Sensor correction

INPUT SHIFT
000.00

- ① Set sensor correction (PV bias).
- ② When measurement range, unit, linear scale etc is changed, setting range and decimal point position may change automatically hence take care.

7. PV decimal point

PV DISPLAY DOT
1

- ① Set the decimal point position of PV.
- ② Based on the decimal point position that is set, up to five digits including the integer part are displayed. Hence only if the number of digits of integer is less, more number of digits after the decimal point can be displayed within the range of decimal point position that is set.
- ③ When measurement range, unit, linear scale etc is changed, setting range and decimal point position may change automatically hence take care.

<p>8. Measurement range</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> RANGE SET - 0 2 0 0 . 0 ~ 1 3 7 0 . 0 </div> <p>[Linear input]</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> RANGE SET 0 0 0 0 . 0 ~ 0 1 0 . 0 0 </div>	<ol style="list-style-type: none"> ① The measurement range that is actually used is set in scale of measurement range. ② For thermocouple and resistance thermometer, the meaning of measurement range is as follows. <ul style="list-style-type: none"> • P of PID operation = Equivalent to 100%. • Maximum set range of SV etc. ③ For linear input, the meaning of measurement range is as follows. <ul style="list-style-type: none"> • Standard range which is the basis of linear scale (with scale). ④ Setting range is within the scale range of the selected measurement range. ⑤ When measurement range changed, setting range and decimal point position may change or it may be initialized hence take care.
<p>9. Linear scale</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> LINEAR SCALE DOT 1 0 0 0 0 . 0 ~ 2 0 0 0 . 0 </div>	<ol style="list-style-type: none"> ① Measurement range is displayed only when 'linear input' is selected. ② Set a scale (with scale) for the standard range that is set in measurement range. P of PID operation = Equivalent to 100%. ③ Set the decimal point position in 'DOT', lower limit value (0%) of the scale on the lower left and upper limit value (100%) on the lower right. ④ When linear scale is changed setting range and decimal point position may change or it may be initialized hence take care.
<p>10. SV decimal point for displaying</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> SV DISPLAY DOT 1 </div>	<ol style="list-style-type: none"> ① Set the decimal point position of SV which is displayed at the upper display. ② Based on the decimal point position that is set, up to five digits including the integer part are displayed. Hence only if the number of digits of integer is less, more number of digits after the decimal point can be displayed within the range of decimal point position that is set. ③ When measurement range, unit, linear scale etc is changed, setting range and decimal point position may change automatically hence take care.

7-8. Mode 6

Mode 6 performs the setting of transmission signal output.

Settings screen	Description of the screen
<p>1. Mode screen</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> MODE <u>6</u> TRANSMITTER </div> <p>[Lock Status]</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> MODE <u>6</u> Lock TRANSMITTER </div> <p>[Display OFF status]</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> MODE <u>6</u> NoDisp TRANSMITTER </div>	<ol style="list-style-type: none"> ① Mode 6 screen. Specifications with transmission signal output only are displayed. ② By clicking the key, 'Lock' and 'No Disp' is displayed. ③ For mode 6 settings screen, if setting change is to be prohibited select 'Lock'. ④ When doing the settings by communications, set all the mode screens to 'Lock'. ⑤ When settings screen of mode 6 is not displayed, select 'NoDisp'.

<p>2. Transmission type</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> TRAN S KIND PV SV MV MFB RSV </div>	<ol style="list-style-type: none"> ① Specifications with transmission signal output only are displayed. ② When 'PV' is selected, measurement value (PV) is transmitted. ③ When 'SV' is selected, setting value (SV) is transmitted. ④ When 'MV' is selected, output value (MV) is transmitted. ⑤ When 'MFB' is selected, actuator feedback value (MFB) is transmitted, but ON-OFF servo type only. ⑥ When 'RSV' is selected, remote SV (RSV) is transmitted. However it can be selected only in case of specifications with remote signal input. ⑦ Remote SV is transmitted even if operation is performed in local SV. ⑧ In case of output 2 specifications, you can select separately 'MV1' on output 1 side and 'MV2' on output 2 side. ⑨ When transmission type is changed setting range and decimal point position may change or it may be initialized hence take care.
<p>3. Transmission scale</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> TRAN S SCALE L-0200.0 ~H1370.0 </div>	<ol style="list-style-type: none"> ① Specifications with transmission signal output only are displayed. ② Set a scale corresponding to transmission signal output (Analog signal). ③ Set lower limit (0%) and upper limit (100%) of the scale for the minimum value (0%) and maximum value (100%) of the transmission signal output. ④ When transmission scale is changed, setting range and decimal point position may change automatically hence take care.

7-9. Mode 7





Mode 7 performs the setting related to communications.
 For details related to communications, read its exclusive instruction manual.

Settings screen	Description of the screen
<p>1. Mode screen</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> MODE 7 COMMUNICATION </div> <p>[Lock Status]</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> MODE 7 Lock COMMUNICATION </div> <p>[Display OFF status]</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> MODE 7 NoDisp COMMUNICATION </div>	<ol style="list-style-type: none"> ① Mode 7 screen. Only the instrument with communications is displayed. ② By clicking the  key, 'Lock' and 'No Disp' is displayed. ③ For mode 7 settings screen, if setting change is to be prohibited select 'Lock'. ④ When doing the settings by communications, set all the mode screens to 'Lock'. ⑤ When settings screen of mode 7 is not displayed, select 'NoDisp'.

<p>2. Communications speed</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>COM BIT RATE</p> <p>9600 bps</p> </div>	<p>① Only the instrument with communications is displayed. ② Set the communications speed.</p>
<p>3. Device number</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>COM NUMBER</p> <p>01</p> </div>	<p>① Only the instrument with communications is displayed. ② Set the device number.</p>
<p>4. Communications function</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>COM KIND</p> <p>COM REM TRANS</p> </div>	<p>① Only the instrument with communications is displayed. ② Set the communications function. ③ If 'COM' is selected it is higher order communications function. ④ If 'REM' is selected, it is communications remote function. ⑤ If 'TRANS' is selected, it is communications transmission function.</p>
<p>5. Communications transmission types</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>COM TRANS KIND</p> <p>PV SV MV MFB RSV</p> </div>	<p>① It only displays with the instrument with communications, and when 'TRANS' is selected. ② Set the communications transmission type. ③ When 'PV' is selected, measurement value (PV) is transmitted. ④ When 'SV' is selected, setting value (SV) is transmitted. ⑤ When 'MV' is selected, output value (MV) is transmitted. ⑥ When 'MFB' is selected, actuator feedback value (MFB) is transmitted, but ON-OFF servo type only. ⑦ When 'RSV' is selected, remote SV (RSV) is transmitted. However it can be selected only in case of specifications with remote signal input. ⑧ In case of output 2 specifications, you can select separately 'MV1' on output 1 side and 'MV2' on output 2 side.</p>
<p>6. Communications protocol</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>COM PROTOCOL</p> <p>MODBUS (RTU)</p> </div>	<p>① Only the instrument with communications is displayed. ② Set communications protocol. ③ If 'MODBUS (RTU)' is selected, MODBUS (RTU) is displayed. ④ If 'MODBUS (ASCII)' is selected, MODBUS (ASCII) is displayed. ⑤ If 'PRIVATE' is selected, CHINO protocol is displayed.</p>
<p>7. Communications character</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>COM CHARACTER</p> <p>8BIT/NON /STOP1</p> </div>	<p>① It only displays with the instrument with communications, and when 'MODBUS' is selected. ② Set communications character (bit length, parity, stop bit).</p>

7-10. Mode 11

Mode 11 performs the setting related to system (Initial settings of the system).

Settings screen	Description of the screen
<p>1. Mode screen</p>  <p>[Lock Status]</p>  <p>[Display OFF status]</p> 	<p>① Mode 11.</p> <p>② By clicking the  key, 'Lock' and 'No Disp' is displayed.</p> <p>③ For mode 11 settings screen, if setting change is to be prohibited select 'Lock'.</p> <p>④ When doing the settings by communications, set all the mode screens to 'Lock'.</p> <p>⑤ When settings screen of mode 11 is not displayed, select 'NoDisp'.</p>
<p>2. Display back light</p> 	<p>① Set the back light color of lower window display.</p> <p>② If 'GREEN' is selected, usually green color is displayed.</p> <p>③ If 'ORANGE' is selected, usually orange color is displayed.</p> <p>④ If 'AUTO' is selected, usually green color is displayed however under the following conditions, orange color is displayed.</p> <ul style="list-style-type: none"> • When any of the alarms is activated. • When an error message is displayed. <p>By valid use of this function, alarm on/off can be judged at a glance.</p>
<p>3. Display contrast</p> 	<p>① It adjusts the contrast of LCD (Liquid crystal display) of lower display window.</p> <p>② Adjust and set the LCD such that the characters are clearly visible. 40 to 70% of range is suitable for setting value. When set the range over or under, stripes appear in the LCD. Do not change the setting (initial value 50%) in ordinary use.</p> <p>③ Contrast especially affects the surrounding temperature hence do this adjustment approximately one hour after switching on the power supply and after the surrounding temperature becomes stable.</p>
<p>4. Key back light</p> 	<p>① It sets the lighting/switch off function of key backlight.</p> <p>② If 'AUTO' is selected, the following operation takes place.</p> <ul style="list-style-type: none"> • Usually it is switched OFF, however when power is supplied or if any of the key is pressed, it illuminates and get switched off if no key operation is done for approximately 30 seconds. <p>③ If 'OFF' is selected, it gets switched OFF.</p> <p>④ If 'ON' is selected, it usually illuminates.</p>

7-11. Initializing the setup parameter

If set contents are to be returned to initial value, you can do it by the following procedure. Once initialization is executed, you will not be able to return to the original setting contents hence take care.

Initialization type	Procedure	Screen that is being initialized
(Initialize the contents of Mode 0 to Mode 11) *Status is factory shipping.	<ol style="list-style-type: none"> ① Cut off the power supply. ② Switch on the power supply while pressing the MODE key. ③ After confirming that the screen shown on the right is displayed, release the MODE key. ④ After the initialization is done, operation screen is displayed. 	<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p style="margin: 0;">P a r a m e t e r</p> <p style="margin: 0;">I n i t i a l i z e</p> </div>

7-12. Precautions while setting

Precautions	Explanation
1. Precautions regarding the setting range.	<ul style="list-style-type: none"> ▪ In parameter for numeric settings, there exists a range of numeric that can be set, hence take care. ▪ If a numeric value exceeding the numeric value range that can be set, is set an error message is displayed. When an error message is displayed confirm the contents of the error message and do the proper settings.
2. When a setting is changed, the set contents of other settings screen may sometimes change.	<ul style="list-style-type: none"> ▪ If the setting of important key parameters is changed, the decimal point position or the setting range of the set value of other related settings screen may sometimes change or may be initialized. ▪ For example if 'measurement range', 'measurement scope', 'linear scale' of mode 5, 'alarm status' of mode 3, transmission type' of mode 6 etc. changed, the set contents of the other settings screen related to them will change. ▪ If the settings of these key parameters is changed, reconfirm the set contents of other settings screen.

7-13. Error message

7-13-1. Usual error display

If proper settings and operation is not done, following error messages are displayed for around 3 seconds. Confirm the contents of the error message and do the proper settings and operation again.

Error message	Error contents
1. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> ERROR No. 2 2 SV RANGE OVER </div>	<ul style="list-style-type: none"> ▪ SV is exceeding the measurement range. ▪ Confirm the measurement range and do the settings again.
2. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> ERROR No. 2 1 INVERTED L > H </div>	<ul style="list-style-type: none"> ▪ L is exceeding H. ▪ Confirm L/H and do the settings again.
3. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> ERROR No. 2 4 INVERTED Z > S </div>	<ul style="list-style-type: none"> ▪ Z is exceeding S. ▪ Confirm Z/S and do the settings again.
4. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> ERROR No. 2 5 LINEAR RANGE OVER </div>	<ul style="list-style-type: none"> ▪ Linear range is exceeding the scope of measurement range. ▪ Confirm the measurement range and do the settings again.

7-13-2. System error display

If an abnormality occurs in the system, the following error messages are displayed for around 2 seconds. Confirm the contents of the error message and contact the dealer or our nearest office.

Error message	Error contents
1. <div style="border: 1px solid black; padding: 5px; width: fit-content;"> SYSTEM ERROR No. 01 CALIBRATION ERROR </div>	<ul style="list-style-type: none"> • Calibration data abnormality
2. <div style="border: 1px solid black; padding: 5px; width: fit-content;"> SYSTEM ERROR No. 10 A/D COUNT : PV </div>	<ul style="list-style-type: none"> • Abnormality in A/D conversion for PV
3. <div style="border: 1px solid black; padding: 5px; width: fit-content;"> SYSTEM ERROR No. 11 A/D COUNT : RJ </div>	<ul style="list-style-type: none"> • Abnormality in A/D conversion for RJ
4. <div style="border: 1px solid black; padding: 5px; width: fit-content;"> SYSTEM ERROR No. 16 A/D COUNT : REMOTE </div>	<ul style="list-style-type: none"> • Abnormality in A/D conversion for remote

7-13-3. Warning display


If proper settings and operation is not done, following error messages are displayed for around 3 seconds. Confirm the contents of the warning message and do the proper settings and operation again.

Warning message	Warning contents
1. <div style="border: 1px solid black; padding: 5px; width: fit-content;"> WARNING No. 10 KEY LOCK </div>	<ul style="list-style-type: none"> • Setting is not changed because of the [Lock] condition at the mode screen. • Change the setting after canceling the [Lock] condition.

8. Initial settings

In '7. Setting screen' setting screen for each mode is explained, but you need not set all of them. The customer should select and set the required parameters depending on the specifications of the controller, system configuration of final product, control conditions etc.

Procedure for setting the minimum limit which is always to be done in the beginning for the finished product is explained here. Do the other settings as per the requirement.



: Always set



: Set as per the requirement

① Set 'measurement range' : Mode 5



② Set 'measurement scope' : Mode 5



③ Setting 'linear scale' : Mode 5



④ Setting 'Direct/reverse' of control operation : Mode 4



⑤ Setting 'SV' : Mode 2



⑥ Setting 'PID' : Mode 3

※Set the measurement range that suits the sensor and the scale range.

※Set the range that is to be actually used. For linear input, set standard range. In case of thermocouple and resistance initial value is also okay.

※Set the scale incase of linear input.

※ Set the control operation.

※ Set the SV.

※ Set the PID.

9. Operation

9-1. Confirmations before operation

Confirm the following contents before starting the operation.

Item	Confirmation contents
1. Wiring	<ul style="list-style-type: none">• Confirm that the wiring is correct. Especially confirm very properly the wiring of high voltage parts like power supply, output and warning. Confirm that the terminal screw is not loose.• Confirm the wiring of not only the controller but also of the entire finished product. Especially proper confirmation of peripherals of actuator (thyristor regulator, heater, motor etc.), product is important.
2. Power supply	<ul style="list-style-type: none">• Confirm that the power supply is in the rating range.
3. Set contents	<ul style="list-style-type: none">• Confirm that the set contents are correct. As soon as the power supply is started the control operation starts. As per the requirement if you do not want to display the output, set something like 0% in manual output operation.



Precautions

- ① If power supply that is out of rating range is connected, the product may get out of order, performance may deteriorate or it may malfunction.
- ② If excess voltage or excess current is applied to input/output terminal of the controller, the product may get out of order, performance may deteriorate or it may malfunction.

9-2. Trial operation

After the confirmations before operation is done, refer to the following and start the trial operation and do various confirmations. This procedure is an example of the most basic trial operation procedure. Add the confirmation contents depending on specifications of the controller, system configuration of finished product, control conditions etc.

- ① Start the power supply. If 0% is possible, then considering the safety make the output of manual output operation as 0% and try making the control output of the controller as 0%.



- ② Confirm that the device configuring the system that includes the controller also, is normal.





③ Confirm that all the signal levels (voltage value, current value, ON/OFF signal etc.) connected between the device configuring the system that includes the controller also, is normal.



④ When output format is current format and thyristor regulator is connected as actuator, do the actuator adjustment (FB zero span settings). Confirm the settings of thyristor regulator. In other output format also, confirm the actuator and do the adjustment as per the requirement.



⑤ Consider that the controller has a status of 0% output due to manual output operation. Output increases gradually, the operation of the actuator is equivalent to the output value and confirms that it is normal.



⑥ Set appropriate SV, switch over from manual output operation to automatic output operation and get the auto control status.



⑦ See the status for a while and if the control is stable then there is no problem. However if the control is unstable, adjust the parameters (PID etc.) of the controller. PID can be calculated automatically also by using the auto tuning function.



⑧ Confirm that operation (Alarm, set switch external input etc.) with peripheral device that is connected to the controller is normal.



⑨ Set each type of parameter of the controller as per the requirement.



⑩ After some time of starting the operation confirm the normality of final product that includes the controller and all the devices configuring the system.

9-3. Automatic output operation and manual output operation

Operation method	Explanation
Automatic output operation (Auto output)	<ul style="list-style-type: none"> ▪ Based on SV of the execution number that is selected and also on the PV that is being measured, perform the control calculation, calculate the control output value and output it. ▪ Usual control operation is this automatic output operation.
Manual output operation (Manual output)	<ul style="list-style-type: none"> ▪ SV and PV output the control output value that is set irrespective of each other. ▪ If you want to switch to manual output operation click the  key and the  key or as per the specifications, switching can be done by setting change external input also. ▪ Relation between switch over by operation screen and that by setting change ▪ Set the output value by  key/ key. Output range is within the output limit. ▪ During automatic and manual switching, the output value does not change suddenly because of balance less bump less function. ▪ During manual output operation, 'M' is added before the word 'OUT' of the operation screen. ▪ Do not switch from manual output to preset manual. ▪ In case of output 2 specifications, switching between automatic/manual can be done separately for operation screen of output 1 side and that of output 2 side. ▪ It is popularly called as manual output.

9-4. Precautions during operation

9-4-1. Change in settings during operation

When changing the settings during operation, any of the settings screen can also be changed. However changing the settings during control operation by using parameter, may adversely affect the control, hence take care.

9-4-2. Precautions when power supply is started

1. P (proportion) operation when starting the power supply

Even though the settings of PID control are done, only the initial control operation at the time of power supply becomes the P (proportion) operation. As a result, due to the conditions the output value becomes very big momentarily during the power supply, hence take care.

2. Countermeasures against the erroneous output during power supply

During the power supply, until the controller starts normally, output related signals may be momentarily output sometimes. Implement the countermeasures against erroneous output as per the requirement by using external circuit.

9-4-3. Precautions during operations of SV slope

During operations of SV slope, the [SLOPE] in the upper display is lighted, and SV is changed with time. Maximum 5 digits of SV are displayed, so that precise operations of SV including decimal point are not displayed. Margin of error of plus or minus 1 digit maximum is observed on the display. However, accurate control calculation is performed in internal processing. The time accuracy of the operation of SV slope is not accuracy at clock level.



Precautions

- ① Take care while changing the settings during operation. It may badly affect the control through the parameters.
- ② Supply a good quality and a stable power supply. The controller may malfunction unexpectedly when it is adversely affected by noise, temporary cut off etc.

10. Detailed explanation of main functions

10-1 Measurement range

The controller is a universal input type or a 4-wire resistance thermometer type and has various measurement ranges. From among them, select the appropriate measurement range from the sensor and the scale range that is to be actually used. For thermocouple and resistance thermometer, confirm the standards and then select the measurement range. Especially 'Pt100Ω' system of thermometers resistance has three types of ratings hence take care.

Displayed measurement range which is set at [measurement range] of mode 5 may be not in order.

[Universal]

No.	Measurement range	Scale range (°C)	Scale range (K)	No.	Measurement range	Scale range (°C)	Scale range (K)		
01	Thermocouple	B	0.0 to 1820.0	273.0 to 2093.0	31	DC voltage	±10mV		
02		R1	0.0 to 1760.0	273.0 to 2033.0	32		±20mV		
03		R2	0.0 to 1200.0	273.0 to 1473.0	33		±50mV		
04		S	0.0 to 1760.0	273.0 to 2033.0	34		±100mV		
05		K1	-200.0 to 1370.0	73.0 to 1643.0	35		±5V		
06		K2	0.0 to 600.0	273.0 to 873.0	37		±10V		
07		K3	-200.0 to 300.0	73.0 to 573.0	36	Direct current	0—20mA		
08		E1	-270.0 to 1000.0	3.0 to 1273.0					
09		E2	0.0 to 700.0	273.0 to 973.0					
10		E3	-270.0 to 300.0	3.0 to 573.0					
11		E4	-270.0 to 150.0	3.0 to 423.0					
12		J1	-200.0 to 1200.0	73.0 to 1473.0	Resistance thermometer	JPt100Ω1	-200.0 to 649.0	73.0 to 922.0	
13		J2	-200.0 to 900.0	73.0 to 1173.0		41	JPt100Ω2	-200.0 to 400.0	73.0 to 673.0
14		J3	-200.0 to 400.0	73.0 to 673.0		42	JPt100Ω4	-200.0 to 200.0	73.0 to 473.0
15		J4	-100.0 to 200.0	173.0 to 473.0		44	JPt100Ω5	-100.0 to 100.0	173.0 to 373.0
16		T1	-270.0 to 400.0	3.0 to 673.0		45	QPt100Ω1	-200.0 to 649.0	73.0 to 922.0
17		T2	-200.0 to 200.0	73.0 to 473.0		46	QPt100Ω2	-200.0 to 400.0	73.0 to 673.0
18		WRe5-26	0.0 to 2310.0	273 to 2583		47	QPt100Ω4	-200.0 to 200.0	73.0 to 473.0
19		W-WRe26	0.0 to 2310.0	273 to 2583		49	QPt100Ω5	-100.0 to 100.0	173.0 to 373.0
20		NiMo-Ni	-50.0 to 1410.0	223 to 1683		50	QPt100Ω5	-100.0 to 100.0	173.0 to 373.0
21		CR-AuFe	0.0 to 280.0 K	0.0 to 280.0		51	JPt50Ω	-200.0 to 649.0	73.0 to 922.0
22		N	0.0 to 1300.0	273.0 to 1573.0		53	Pt100Ω1	-200.0 to 850.0	73.0 to 1123.0
23		PR5-20	0.0 to 1800.0	273.0 to 2073.0		54	Pt100Ω2	-200.0 to 400.0	73.0 to 673.0
24		PtRh40-20	0.0 to 1880.0	273.0 to 2153.0		56	Pt100Ω4	-200.0 to 200.0	73.0 to 473.0
25		Platill1	0.0 to 1390.0	273.0 to 1663.0		57	Pt100Ω5	-100.0 to 100.0	173.0 to 373.0
26		Platill2	0.0 to 600.0	273.0 to 873.0					
27		U	-200.0 to 400.0	73.0 to 673.0					
28		L	-200.0 to 900.0	73.0 to 1173.0					

[4-wire resistance thermometer]

No.	Measurement range	Scale range (°C)	Scale range (K)	No.	Measurement range	Scale range (°C)	Scale range (K)		
41	Resistance thermometer	JPt100Ω1	-200.0 to 649.0	73.0 to 922.0	50	Resistance thermometer	QPt100Ω5	-100.0 to 100.0	173.0 to 373.0
42		JPt100Ω2	-200.0 to 400.0	73.0 to 673.0	51		JPt50Ω	-200.0 to 649.0	73.0 to 922.0
44		JPt100Ω4	-200.0 to 200.0	73.0 to 473.0	52		Pt-Co	4.0 to 374.0 K	4.0 to 374.0
45		JPt100Ω5	-100.0 to 100.0	173.0 to 373.0	53		Pt100Ω1	-200.0 to 850.0	73.0 to 1123.0
46		QPt100Ω1	-200.0 to 649.0	73.0 to 922.0	54		Pt100Ω2	-200.0 to 400.0	73.0 to 673.0
47		QPt100Ω2	-200.0 to 400.0	73.0 to 673.0	56		Pt100Ω4	-200.0 to 200.0	73.0 to 473.0
49		QPt100Ω4	-200.0 to 200.0	73.0 to 473.0	57		Pt100Ω5	-100.0 to 100.0	173.0 to 373.0

[Standard list]

K, E, J, T, R, S, B, N: IEC584 (1977,1982), JIS C 1602-1995, JIS C 1605-1995

WRe5-WRe26, W-WRe26, NiMo-Ni, Platinel II, CR-AuFe, PtRh40-PtRh2: ASTM Vo1.14.03

U, L: DIN43710-1985

Pt100: IEC751 (1995), JIS C 1604-1997

QPt100: IEC751 (1983), JIS C 1604-1989, JIS C 1606-1989

※QPt100Ω is also called old PT100Ω.

JPt100: JIS C 1604-1981, JIS C 1606-1986

JPt50: JIS C 1604-1981

10-2 .Linear scale

If linear input (DC voltage and current) is selected, initial value of linear scale and measurement range is as follows.

Measurement range	Scale range	Measurement range (Initial value)	Linear scale (Initial value)
31 10mV	- 10.0 to 10.0 mV	0.00 to 10.00 mV	0.0 to 2000.0
32 20mV	- 20.0 to 20.0 mV	0.00 to 20.00 mV	0.0 to 2000.0
33 50mV	- 50.0 to 50.0 mV	0.00 to 50.00 mV	0.0 to 2000.0
34 100mV	-100.0 to 100.0 mV	0.00 to 100.00 mV	0.0 to 2000.0
35 5V	0.0 to 5.0 V	0.000 to 5.000 V	0.0 to 2000.0
37 10V	-10.0 to 10.0 V	0.000 to 10.000 V	0.0 to 2000.0
36 20mA	0.0 to 20.0 mA	4.00 to 20.00 mA	0.0 to 2000.0


Setting procedure is as follows.

- ① For 'measurement range' of mode 5, set the minimum value and the maximum value of the analog signal that is actually input from the sensor.
- ② Nextly for 'linear scale' of mode 5, after confirming how to display that minimum value and maximum value set the decimal point position and lower limit and upper limit of the scale.
- ③ For example, for 4-20 mA if you want to display 0.00-100.00, the settings are as follows.
 - Measurement range: 4.000 (minimum value) – 20.000 (Maximum value).
 - Linear scale : DOT2.
0.00 (Lower limit) -100.00 (Higher limit).

10-3. Alarm mode

Following are the 8 types of alarm formats.

- ① DH (Deviation high limit alarm) : Alarm is ON when SV (setting value)+ Alarm setting value is more than PV (measurement value).
- ② DHW (Deviation high limit wait alarm) : When high limit deviation alarm has a wait function and when power is supplied, the status is alarm ON until it once enters the normal range. At the time of supplying power if SV is changed, alarm value is changed etc. the status becomes wait status.
- ③ DL (Deviation low limit alarm) : Alarm is ON when SV (setting value)+ Alarm setting value is more than PV (measurement value).
- ④ DLW (Deviation low limit wait alarm) : When low limit deviation alarm has a wait function and when power is supplied, the status is alarm ON until it once enters the normal range. At the time of supplying power if SV is change, alarm value is changed etc. the status becomes wait status.
- ⑤ AH (Absolute value high limit alarm) : Alarm is ON when PV (measurement value) is more than alarm setting value.
- ⑥ AHW (Absolute value high limit wait alarm) : When high limit absolute value alarm has a wait function and when power is supplied, the status is alarm ON until it once enters the normal range. At the time of supplying power if SV is changed, alarm value is changed etc. the status becomes wait status.
- ⑦ AL (Absolute value low limit alarm) : Alarm is ON when PV (measurement value) is less than alarm setting value.
- ⑧ ALW (Absolute value low limit alarm wait) : When low limit absolute value alarm has a wait function and when power is supplied, the status is alarm ON until it once enters the normal range. At the time of supplying power if SV is changed, alarm value is changed etc. the status becomes wait status.



10-4. Execution number and 8 parameters

This parameter can set in a group of 8 the important parameters related to control including SV also. This set of 8 is registered as execution number 1 to 8 and just by selecting that execution number operation can be executed immediately by a totally different parameter.

In parameter in which 8 types of settings are possible, are as follows.

- SV 8 types : See mode 2.
- PID 8 types : See mode 3.
- Alarm 1 and alarm 2 8 types : See mode 3.
- Alarm 3 and alarm 4 8 types : See mode 3.
- Output limiter 8 types : See mode 4.
- Output change quantity delimiter 8 types: See mode 4.

The number 1 to 8 of the above parameters corresponds to execution numbers 1 to 9.

Execution number is selected by External set value switching (restricted to specifications with External set value switching) or 'select execution number' of mode 1.

10-5. Auto tuning

Auto tuning (AT) is a function that automatically calculates PID constant.

It is an auto tuning function of output 1 side.

Auto tuning can be started during normal operation (during automatic output operation) and can be executed by executing SV.

PID calculated by AT is registered in PID of executing PID No..

In case of output 2 specifications, MV (output value) on output 2 side during nonexecutable AT is continued control.

Sometimes even on starting the auto tuning operation normally, PID is not requested. Conditions when it is not requested are as follows. In that case PID constants are not changed and the original PID constants remain.

- When response is delayed too much, when it does not end even after around six hours of auto tuning operation.
- When the value of P calculated by auto tuning is less than 0.1% or more than 1000%.
- When the value of I calculated by auto tuning is less than 1 second.
- When the value of D calculated by auto tuning is less than 1 second.

10-6. PID control

PID is the most generic control algorithm in which consists of three operations namely P (Proportion), I (Integration) and D (Differentiation).

① P operation

- It is the basic operation of PID control. It largely affects the responsiveness and the stability. Offset occurs only in proportion operation.
- If P is increased, the amplitude of PV (measurement value) becomes less and the stability improves however the responsiveness deteriorates.
- By setting $P=0\%$ two-position control operation takes place.



② I operation

- Offset due to P operation can be eliminated however as the phase is delayed stability deteriorates.
- If I is reduced (integral operation is strengthened), responsiveness improves, over shoot increases.
- Setting value '0' is equivalent to ∞ (infinity).

③ D operation

- It compensates the time that is wasted and delay in phase due to delayed elements. However as gain in high frequency area increases, there is a limit for the strength.
- If D is increased, responsiveness increases for a large deviation, however for quick periodic deviations stability deteriorates.
- '0' of the settings value is equivalent to OFF.
- The setting value of D, is $1/6^{\text{th}}$ to $1/4^{\text{th}}$ the setting value of I and it is generic.

Collectively the PID operation is as follows.

	P (Proportion) operation	I (Integration) operation	D (Differentiation) operation
Input			
Output			

The controller had 2 types of PID control algorithms installed, either of it can be selected.

① POSITION

- Position type PID system.
- Comparatively, response is valid for control target.

② VELOCITY

- Speed type PID system.
- Comparatively, response is valid for quick control target.

For theory and details of PID control see its special literature.

10-7. Actuator adjustment of ON-OFF servo type

If the output format is ON-OFF servo type, the controller and the actuator (motor etc.) should be adjusted. Do the adjustment basically by auto adjustment. Fine adjustment can be done manually also, however if you are using it for the first time, use the automatic adjustment first and then the manual fine adjustment. When auto adjustment is not performed, output value of output display screen and feedback value have a margin of error.

1. Auto adjustment

① Initializing the setting value

- Before the adjustment, consider the setting value of 'FB dead band' of mode 4 as the setting value.
- For initial value, the dead band becomes 1.0%.
- Other than that for output in the range of 0-100%, confirm each parameter.

② Zero span adjustment

- Select 'START' in 'FB tuning' of mode 4, press **ENT** key and start FB tuning, and then adjusted data of feedback which is displayed at output display screen is initialized.
- The actuator automatically runs on **CLOSE** side and **OPEN** side and calculates the value automatically.
- When FB tuning is completed, return to 'END'.
- The automatically calculated zero span value is automatically registered in 'FB zero span' of mode 4 hence confirm it.

③ Dead band adjustment (Gain adjustment)

- See ⑤ of "Manual adjustment".

If the movement of actuator is delayed too much, auto calculation by 'FB tuning' is not possible. In that case after a fixed period return to 'END' and zero span value is not registered.

2. Manual adjustment

① Initializing the setting value

- Before the adjustment, return the setting value of 'FB dead band' and 'FB zero span' of mode 4 to initial value.
- Initial values are zero is 0.0%, span is 100.0% and dead band is 1.0%.
- Other than that for output in the range of 0-100%, confirm each parameter.

② Zero adjustment

- Perform manual output operation (manual output) and set the output value to 0.0%.
- Actuator scales out on **CLOSE** side.
- Increase the output value by 0.1% every time and request an output value that erases **CLOSE** display.

③ Span adjustment

- Similarly the output value is set to 100.0%.
- Actuator scales out on **OPEN** side.
- Decrease the output value by 0.1% every time and request an output value that erases **OPEN** display.

④ Registering zero span value

- Set the output value requested in ① and ②, in 'FB zero span' of mode 4 respectively.

⑤ Dead band adjustment (Gain adjustment)

- Successively, similarly set the output value to 50.0%.
- Increase the setting value a little every time in 'FB dead zone' of mode 4 and request a setting value that erases both the displays of **OPEN** and **CLOSE** of the operation screen.
- Perform a trial operation, increase the setting value little by little until the range where is no error in controllability and set the greatest value as the settings value of final 'FB dead band'.

10-8. Output 2


Output 2 specifications of the controller have enabled simultaneous control of heating and cooling.

PID of output 2 and gap between output 1 and output 2 can be set.

Usually, consider output 1 as heating operation and set 'direct/reverse controlling operation' of mode 4 as 'REVERSE' and consider output 2 as cooling operation and set 'direct/reverse controlling operation' of mode 4 as 'DIRECT'.

Gap is as shown in the figure below. It is called the gap between SV and 0% of output 2 (For proportion band).


When both output 1 and output 2 are $PV=SV$, if you want output to be 50% (When I operation and D operation are not included), it can be done by requesting a gap $G(\%) = -P/2$ (P: Proportion band of output 2, output 2 is direct operation).



10-9. Transmission signal output

It is a function that selects one type from PV (measurement value), SV (measurement value), MV1 (Output value 1), MV2 (Output value 2), MFB (feedback value), RSV (Remote SV) and outputs using analog signal.


For example it is used in applications like, selecting a PV transmission and connecting that analog signal to the recorder and recording the PV of this controller in the recorder. Specifications of analog signal are specified in a format.



※Parallel connection of sensor signal of controller and recorder is prohibited. Consequently, PV transmission shall be used.

The following occurs when transmission signal output with 4-20mA specified and measurement range K1 and in a range of 0-1200°C transmits PV.


- Set 'PV' in transmission type of mode 6 and '0-1200' in 'transmission scale'.



10-10. Remote signal input


A function that enables the SV setting by using analog signal from outside.

For example by connecting to controller the SV transmission of program controller, you can use it as simple program controller. Specifications of analog signal are specified in a format.




The following occurs when remote signal input with 4-20mA specified and in a range of 0-1200°C performs remote SV.

- Set '0 to 1200' in 'remote scale' mode 2.
- Select 'remote' in external signal input (R/L) and 'REMOTE' in 'remote/local switching' of mode 1.




- Set 'remote shift' and 'remote filter' of mode to as per the requirement.

In case of specifications with remote signal input, it can be used as secondary regulator of cascade control loop. Calculation block of cascade control is as follows.



Get the ratio r and bias b by referring to the following diagram.



Cascade control contains an experimental factor and requires a lot of control theory knowledge. Controller has a function that can set cascade constant, however cascade control cannot be assured by using this function.

10-11. External set value switching

In case of specifications with external set value switching, the controller can have a functionality of selecting execution number from conductive signal (ON/OFF) of external no voltage contact signal (relay, switch, open collector signal).

Further, in case of specifications with external set value switching, by using special specifications (specified during your order), 'external A/M switching' or 'Preset manual' functionalities can be added.

Function name	Description																																													
1. SV1 SV2 SV4 SV8	<ul style="list-style-type: none"> It is a function for selecting execution number from external signal input. Selection of execution number is based on control signal from BCD code. Control the fixed external signal input using continuous signal. Depending on the execution number to be selected, external signal input with ○ mark is conducted (ON) as follows. After conduction (ON) execution number is selected in around 0.5 seconds or more. <table border="1"> <thead> <tr> <th></th> <th>Execution No.8</th> <th>Execution No.7</th> <th>Execution No.6</th> <th>Execution No.5</th> <th>Execution No.4</th> <th>Execution No.3</th> <th>Execution No.2</th> <th>Execution No.1</th> </tr> </thead> <tbody> <tr> <td>SV8</td> <td>○</td> <td>×</td> <td>×</td> <td>×</td> <td>×</td> <td>×</td> <td>×</td> <td>×</td> </tr> <tr> <td>SV4</td> <td>×</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>×</td> <td>×</td> <td>×</td> </tr> <tr> <td>SV2</td> <td>×</td> <td>○</td> <td>○</td> <td>×</td> <td>×</td> <td>○</td> <td>○</td> <td>×</td> </tr> <tr> <td>SV1</td> <td>×</td> <td>○</td> <td>×</td> <td>○</td> <td>×</td> <td>○</td> <td>×</td> <td>○</td> </tr> </tbody> </table> <ul style="list-style-type: none"> When BCD code other than that mentioned above (execution number 1 to 8) is selected, the execution number that was being executed before selection remains. When selecting the execution number from 'Select execution No.' of mode 1, select BCD code other than that mentioned above for external signal input (execution number 1 to 8). Generally consider all the four external input signals as non conductive (BCD code:0). Then select the execution number from 'Select execution No.' of mode 1. 		Execution No.8	Execution No.7	Execution No.6	Execution No.5	Execution No.4	Execution No.3	Execution No.2	Execution No.1	SV8	○	×	×	×	×	×	×	×	SV4	×	○	○	○	○	×	×	×	SV2	×	○	○	×	×	○	○	×	SV1	×	○	×	○	×	○	×	○
	Execution No.8	Execution No.7	Execution No.6	Execution No.5	Execution No.4	Execution No.3	Execution No.2	Execution No.1																																						
SV8	○	×	×	×	×	×	×	×																																						
SV4	×	○	○	○	○	×	×	×																																						
SV2	×	○	○	×	×	○	○	×																																						
SV1	×	○	×	○	×	○	×	○																																						
2. MAN1/ AUTO1 ※ Option	<ul style="list-style-type: none"> It is a function that can be executed only in case of specifications with external A/M switching (option). It is a function for switching between manual output operation (manual output) and automatic output (auto output) operation of output 1 side through external signal input. Fixed external signal input is controlled by continuous signal. In around 0.5 seconds or more after conduction (ON), it is manual output operation and in around 0.5 seconds or more after non-conduction (OFF), it is automatic output operation. When switching between MAN/AUTO by using external signal input, 'AUTO' is selected by key operation on operation screen. Then switching is done by external signal input. In case of manual output switching, 'e' is displayed on the left of 'OUT' of the operation screen. <p>The image shows a digital display with a black background and white text. At the top, there is a row of ten small white squares. Below this, the text 'e OUT :100.0%' is displayed in a pixelated font. The 'e' is on the left, followed by 'OUT', a colon, and '100.0%'.</p>																																													

Function name	Description
<p>3. MAN2/AUTO2 ※ Option</p>	<ul style="list-style-type: none"> ▪ It is a function that can be executed only in case of specifications with external A/M switching (option) and output 2 specifications. ▪ It is a function for switching between manual output operation (manual output) and automatic output (auto output) operation of output 2 side through external signal input and only output 2 specifications can be selected. ▪ Fixed external signal input is controlled by continuous signal. In around 0.5 seconds or more after conduction (ON), it is manual output operation and in around 0.5 seconds or more after non-conduction (OFF), it is automatic output operation. ▪ In case of manual output switching, 'e' is displayed on the left of 'OUT' of the operation screen. 
<p>4. PRESET/AUTO ※ Option</p>	<ul style="list-style-type: none"> ▪ It is a function that can be executed only in case of specifications with preset manual (option). ▪ It is a function for switching between output preset operation (preset manual output) and automatic output (auto output) operation through external signal input. ▪ Fixed external signal input is controlled by continuous signal. In around 0.5 seconds or more after conduction (ON), it is output preset operation and in around 0.5 seconds or more after non-conduction (OFF), it is automatic output operation. ▪ When switching from automatic output operation to output preset operation is done, MV (output value) becomes the set value as a result of change rate that is set in output variation limiter No. 9. When switching from output preset operation to automatic output operation is done, an auto output results due to balance bump less operation. ▪ In case of output preset operation, output value becomes the setting value of 'preset manual' of mode 4, warning operation is executed and auto tuning cannot be executed. ▪ In case of preset manual output switching, 'p' is displayed on the left of 'OUT' of operation screen. 

10-12. Communications interface

The controller is provided with various communications functions and they are as follows.

10-12-1. Engineering port

It is a communications function provided in all the products. Engineering port exists on the right side on the front after opening the lower cover of the front part. Communications with the PC can be done by connecting an exclusive engineering cable (sold separately).

Specifications of communications by using the engineering port is as follows.

- Communications protocol : MODBUS-RTU
- Communications speed : 9600bps
- Communications character : bit length 8/parity NON/stop bit 1

10-12-2. Specifications with communications

Usually when doing communications, select specifications with communications. Type of communications can be selected from amongst RS232C, RS422A and RS485.


Communications enables the setting of parameters (Data Write) and data reading (Data Read) by connecting to PC and remote operation for which PC is used and data management can be done. There is one more functionality namely communications transmission (digital transmission) function/communications remote (digital remote) function. This function enables realization of a remote operation without any error by sending the SV transmission by using communications and receiving it as remote SV by using communications. Remote operation due to remote signal input is called Analog Remote and on the other hand remote operation due to communications remote is called Digital Remote.

11. Engineering port


This function can connect with the PC from the front of the controller. Even if this function is not in the specifications with communication interface, it is provided as standard to all products.

An exclusive engineering cable is inserted in this port and connected to the PC.

Parameter setup software 'PASS' is available with our company. Various parameters can be easily set from the front of the controller by using this 'PASS' and engineering cable, and PC.



Engineering port



Engineering cable

Engineering port is used for temporary communication connection on that structure and is not for usual connection.

If you want to carry out the communication by usual connection, while purchasing specify specifications with communication interface and do a permanent connection from the back side.



Precaution

Connecting and disconnecting of engineering cable to engineering port in this instrument should be done while applying power.

12. Trouble shooting

Condition	Items to be confirmed
1. There is an error in PV or PV is not stable	<ul style="list-style-type: none"> ▪ Confirm that there is no problem in the wiring with the sensor. ▪ For thermocouple, confirm that wiring is done till the terminal screw by using thermocouple and compensation lead wire. ▪ Confirm that the terminal screws are tightened properly. ▪ Confirm that sensor signal is not connected in parallel with other instrument. ▪ Confirm that protective elements etc are connected to sensor signal and the impedance does not become high. ▪ Confirm that there is no problem in output specifications (impedance etc.) and output signal of sensor itself. ▪ Confirm that ground terminal is connected to good quality protective ground. ▪ Confirm that there is no noise. ▪ Confirm that there is no problem in the environment and atmosphere (surrounding temperature, wind etc.) ▪ Confirm that set contents of various parameters (Measurement range, sensor correction, customer scale calibration etc) are correct.
2. PV display becomes '-----'.	<ul style="list-style-type: none"> ▪ It indicates excessive input or higher limit burn out for measurement range. Confirm the sensor signal.
3. PV display becomes '-----'.	<ul style="list-style-type: none"> ▪ It indicates very little input or lower limit burn out for measurement range. Confirm the sensor signal.
4. Control is not stable.	<ul style="list-style-type: none"> ▪ Confirm that there is no problem with the wiring of the actuator. ▪ Confirm that the terminal screw is tightened properly. ▪ Confirm that there is no noise. ▪ Confirm that the set contents of various parameters (PID, output limiter etc.) are correct. <p>× Regarding controllability, it is necessary to do the design/adjustment not only in just the controller but in the entire system of the final product. If the controllability does not improve even on adjusting the set contents of various parameters (PID etc.) of the controller, consult the designer of this final product.</p>
5. 'ERR' of status display lights.	<ul style="list-style-type: none"> ▪ It indicated abnormality in taking the input. In addition to chances of abnormality in the internal circuit of the controller, it might be adversely affected by noise also, hence confirm that there is no noise.
6. Cause unclear however operation is strange	<ul style="list-style-type: none"> ▪ Confirm that the contents of various parameters are correct. ▪ Even then if the operation of the controller is strange, initialize the set contents. Do all the settings again and confirm that there is no problem in it.

Condition	Items to be confirmed
7. Lower display is not displayed normally, displayed strips.	<ul style="list-style-type: none"> ▪ Set the proper value of the [Display contrast] in mode11. 40 to 70% of range is suitable setting value. When setting the range of 80 to 100%, stripes appear in the LCD. The setting value is set the initial value (50%) in ordinary use.
8. Error message is displayed when setting the parameter	<ul style="list-style-type: none"> ▪ After confirming error message, change to the correct setting because of the setting which is not registered.
9. Error message is displayed when starting operations	<ul style="list-style-type: none"> ▪ After confirming error message, change to the correct setting because of the setting which is not started operation.

When problems are not improved after executing the above troubleshooting, contact the dealer or your local CHINO's sales agent.

 Warning	<p>When repair or modification of this instrument is needed, contact the dealer or your local CHINO's sales agent. Make sure that no persons other than service engineers approved by CHINO CORPORATION do not repair or modify this instrument by replacing parts.</p> <p>The data of settings may be deleted during repairing for unexpected trouble (power failure, earthquake, or other unexpected accident).</p> <p>Backup the data of settings before having the instrument repaired. We are not responsible for the lost or damaged data.</p>
--	--

13. Checking and maintenance

13-1. Checking

13-1-1. Checking according to the trial operation

Every time before starting the operation do a trial operation and confirm that the final product is correct.

13-1-2. Checking the accuracy

For the controller, depending on the requirement of the client periodical accuracy checking like measurement accuracy of PV (measurement value), accuracy of transmission signal etc. is necessary. Due to secular changes, these may slightly drift from accuracy, from the time when it was purchased.

Accuracy checking is done in our company hence consult your dealer or our company's nearest office.

13-1-3. Overhaul

Since the controller is reliable, we recommend an overhaul after 2-3 years. For ordering overhaul contact your dealer or our company's nearest office.

13-2. Life component

Clear life component of the controller is as follows.

Please understand that secular changes and aging occurs in almost all the products.

Component name	Estimated life
1. Relay × Relay for control, relay for alarm.	Approximately one hundred thousand times
2. Electrolysis condenser × Condenser for smoothness of electric circuit.	Approximately 5 years (Surrounding temperature: 30°C, operation time: 12 hours/day)



13-3. Disposal








Precaution



- ① A small amount of hazardous substance below the specified level with RoHS directive is included in this controller.
- ② When disposing the controller always request a professional to do it, or dispose the controller in according to the garbage collection method of the each community.
- ③ Separate the box, plastic bags, and cushioning materials the controller is packaged in according to the garbage collection method of the each community, and please cooperate to recycle.

14. Explanation of terms

Term	Explanation
Unit	<p>Only for thermocouple or resistance thermometer select °C or K. Operation equation is as follows.</p> <ul style="list-style-type: none"> • °C = K - 273.15 • K = °C + 273.15
RJ (Reference Junction)	<p>Thermocouple has measurement junction (temperature measurement side) and reference junction (electromotive force generation side) and reference junction decides the standards of thermo-electromotive force table at 0°C condition.</p>  <p>When connecting the thermocouple to terminal of the controller, usually the temperature of the terminal becomes same as the surrounding temperature and is not 0°C. As a result, unless that temperature is compensated correct temperature cannot be measured. That compensation that is done automatically in the product internally is called the compensation function 'RJ'.</p>
Sensor correction	<p>It is a function that corrects the PV (measurement value). It can also be used as zero point adjustment of sensor signal.</p>
PV decimal point	<p>It is a function that enables the selection of decimal point function of PV (measurement). Decimal point position can be selected from 5 digits display.</p>
SV decimal point for display	<p>This is a function for changing position of the decimal point of SV at the upper display. For example, when number of digits after decimal point is not displayed, use this function.</p>
Digital filter	<p>It is a filter function on the operation having first order lag in PV (measurement value). Setting value of digital filter is equivalent to time constant (T), and when PV is changed during step condition it is equivalent to the time (seconds) to reach approximately 63%.</p> 

Term	Explanation
Output limiter	<p>It is a function that sets higher limit and lower limit in a range from -5.0 to 105% in MV.</p> <p>All the MVs (output value) on the control, lie within the range of higher limit and lower limit that is set.</p> 
Output scale	<p>It is a function that lays out MV from 0.0 to 100%, in a range from higher limit value to lower limit value that is set.</p> <p>All the MVs (output value) on the control, lie within the range of higher limit and lower limit that is set.</p> <p>※ Option (Specify when placing an order)</p> 
Output variation limiter	<p>It is a function that limits the variation quantity of MV (output value), for each control cycle (approximately 0.1 seconds). For example when variation in MV is 50% and set value of output variation limiter is 5%, then approximately 0.1 seconds x 50 / 5 = approximately 1.0 seconds, to arrive to a variation of 50% approximately 1.0 seconds are required.</p> <p>By using this function appropriately, sudden variation in MV (output value) can be avoided and controllability can be improved.</p> <p>However, manual output (include immediately after switching manual to auto) and output during PV abnormality are not effect this function.</p>
Output preset	<p>It is a function that can set MV (output value) when SV = PV, when controlling only the P (proportion) operation.</p>
Preset manual	<p>It is a function that sets MV (output value) by external signal input only when external set value switching is specified.</p> <p>※ Option (Specified when you place an order).</p>

Term	Explanation
Output at the time of PV abnormality	<p>It is a function that considers forcibly MV (output value) as set value when, PV (measurement value) exceeds the range (including higher limit burnout), is below range (including lower limit burnout).</p> <p>Separate settings can be done in case of over range (including higher limit burnout) and under range (including lower limit burnout). In case of internal data abnormality, MV (output value) is the same as that in case of over range (including higher limit burnout).</p> <p>In case of output 2 specifications, output 2 side is 0% for all conditions.</p>
Pulse cycle	<p>It is a function that sets one cycle time of output ON/OFF in case of ON-OFF pulse type or SSR drive pulse type.</p> <p>The smaller the set value the better the controllability, however as the ON/OFF count increases the life span of relay etc. decreases. Set the highest possible value in the range such that there is no error in controllability.</p>
Control operation	<p>'Reverse operation' is a control operation for SV (Setting value) in which the lower the PV (measurement value) the bigger the MV (output value) and it is generally used at the time of heating operation.</p> <p>'Direct operation' is a control operation for SV (Setting value) in which the higher the PV (measurement value) the bigger the MV (output value) and it is generally used at the time of cooling operation.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>[Reverse operation]</p>  </div> <div style="text-align: center;"> <p>[Direct operation]</p>  </div> </div>
Output dead band (Two-position control operation)	<p>It is a dead band of output operation of two-position control operation (when P=0%).</p> <p>The smaller the set value the better the controllability, however as the ON/OFF count increases the life span of relay etc. decreases. Set the highest possible value in the range such that there is no error in controllability.</p> <div style="text-align: center;"> <p>[For reverse operation]</p>  </div>


Term	Explanation
Alarm dead band	<p>It is a function that, activates the alarm at the alarm setting value during alarm activation and releases the alarm, when the dead band that is set in the alarm setting value exceeds the dead band that is set in alarm setting value during alarm release.</p> 
A.R.W (Anti reset windup)	<p>It is a function that decides the range of PID operation (especially I operation) in position type PID control. If this set value is exceeded, it becomes a PD operation.</p> 
PV start	<p>It is one of the functions in slope operation according to the SV change rate. This function is the SV (set value) is started from current PV (measurement value) when recovery from power failure or switch manual operation to auto operation.</p> <p>For example, when PV is 110°C and SV is changed from 100°C to 150°C, at that time the slope operation is started from PV after turning off the power at 105°C that is the middle of the slope of the SV and then turning on the power. In other words, it is started from 110°C in this case. If PV is over range or under range, SV after returning on the power is displayed 150°C of changed value.</p>

15. Accessories

15-1. Front protective cover

It is a cover for protecting the front part also to protect the keys from being tampered.

During closed installation, it is not mounted but it is with front protective cover, the panel mounting interval of the controller is 105 mm or more.



15-2. Contact protection element


Contact protection element is connected for noise rejection to the relay output terminal of the controller. Always do the loading and wiring through contact protection element and buffer relay in relay output like ON-OFF pulse type, ON-OFF servo type and alarm output.

Contact protection element as shown below is available with our company also, use it as per your requirement.

Model	Specifications	Open close current	Application
CX-CR1	0.01 μ F + 120 Ω	Less than 0.2A	For light load
CX-CR2	0.5 μ F + 47 Ω	0.2A or more	For heavy load

While using it, the leak current flows depending on the load power supply as shown below hence take care.

Model	Power voltage: 200V		Power voltage: 100V	
	50Hz	60Hz	50Hz	60Hz
CX-CR1	Approximately 2mA	Approximately 2mA	Approximately 1mA	Approximately 1mA
CX-CR2	Approximately 45mA	Approximately 55mA	Approximately 23mA	Approximately 28mA



16. Specifications

■ Input specifications

Input signal:

Thermocouple B, R, S, K, E, J, T, WRe5-WRe26, W-WRe26, NiMo-Ni, CR-AuFe, N, PR5-20, PtRh40-PtRh20, PlatineI II, U, L

DC voltage $\pm 10\text{mV}$, $\pm 20\text{mV}$, $\pm 50\text{mV}$, $\pm 100\text{mV}$, $\pm 5\text{V}$, $\pm 10\text{V}$

DC current 0 to 20mA

Resistance thermometer Pt100, JPt100, Old Pt100, Pt50, Pt-Co (4-wire)

Measurement range: Thermocouple 28 types, DC voltage 6 types, DC current 1 type, resistance thermometer 14 types

Temperature unit: °C, K

Accuracy rating: $\pm 0.1\% \pm 1$ digit of measurement range

For details see, 'Detailed accuracy rating specifications'.

Reference junction compensation accuracy: $\pm 0.5^\circ\text{C}$

For details see, 'Reference junction compensation accuracy'.

Sampling rate: Approximately 0.1 seconds

Resolution : Approximately 1/30000

Burnout: Restricted to thermocouple, DC voltage (less than $\pm 50\text{mV}$), resistance thermometer (3-wire), high limit burnout is a standard provision. During burnout, output value of output 1 can be set optionally, output value of output 2 is 0% and high limit alarm is ON (during high limit burnout) however DC voltage ($\pm 100\text{mV}$ or more), DC current, resistance temperature (4 wire system) are not provided.

Input impedance: Thermocouple 1M Ω or more
DC voltage 1M Ω or more
DC current approximately 250 Ω

Allowable signal source resistance:

Thermocouple Less than 100 Ω
DC voltage (mV) Less than 100 Ω
DC voltage (V) Less than 300 Ω

Allowable wire resistance: Resistance thermometer
Less than 5 Ω (Should be common for all wires)

Measurement current of resistance thermometer:
Approximately 1mA

Maximum allowable input:

Thermocouple Less than $\pm 20\text{V}$
DC voltage Less than $\pm 20\text{V}$
DC current Less than $\pm 30\text{mA}$,
Less than $\pm 7.5\text{V}$
Resistance thermometer Less than 500 Ω ,
Less than $\pm 5\text{V}$

Maximum common mode voltage: Less than 30VAC

Common mode rejection ratio: 130dB or more (50/60Hz)

Normal mode rejection ratio: 50dB or more (50/60Hz)

■ Display specifications

Upper display: LED

Lower display: LCD (with back light) 108x24 dot

■ Control specifications

Control cycle: Approximately 0.1 seconds

Output format: ON-OFF pulse type, ON-OFF servo type, Current output type, SSR drive pulse type, voltage output type

ON-OFF pulse type:

Output signal: ON-OFF pulse conductive signal

Contact capacity Resistance load
Less than 100 to 240VAC and 5A
Less than 30VDC and 5A
Inductive load
Less than 100 to 240VAC and 2.5A
Less than 30VDC and 2.5A
Smallest load
5VDC and 10mA or more

Contact protection

Build in a small type of CR device

ON-OFF servo type:

Output signal: ON-OFF servo inductive signal

Contact capacity of standard load
Resistance load
Less than 100 to 240VAC and 5A
Less than 30VDC and 5A
Inductive load
Less than 100 to 240VAC and 2.5A
Less than 30VDC and 2.5A
Smallest load
5VDC and 10mA or more

Contact capacity of light load

Resistance load
Less than 100 to 240VAC and 20mA
Less than 30VDC and 20mA
Inductive load
Less than 100 to 240VAC and 20mA
Less than 30VDC and 20mA
Smallest load
5VDC and 1mA or more

Contact protection

Build in a small type of CR device

Current output type

Output signal 4 to 20mA
Load resistance Less than 750 Ω

SSR drive pulse type

Output signal ON-OFF pulse voltage signal
Output voltage ON voltage 12VDC $\pm 20\%$
OFF voltage less than 0.8VDC
Load current Less than 20mA

Voltage output type

Output signal 0 to 10V
Output impedance Approximately 10 Ω
Load resistance 50k Ω or more

■ Alarm specifications

Alarm points: 4 points

Alarm type: Absolute value alarm, deviation alarm

Output signal: Relay output signal ("a" contact)

COM common for AL1 and AL2, COM common for AL3 and AL4

Contact capacity

Resistance load Less than 100 to 240VAC and 3A
Less than 30VDC and 3A

Inductive load Less than 100 to 240VAC and 1.5A
Less than 30VDC and 1.5A

Smallest load 5VDC and 10mA or more

■ General specifications

Rated power voltage: General power supply specifications
100 to 240VAC

24V Power supply specifications
24VAC/24VDC

Rated power supply frequency:

General power supply specifications
50/ 60Hz

24V Power supply specification
DC, 50/60Hz

Maximum power consumption:

General power supply specifications
Without option 100VAC 10VA
240VAC 15VA
With option 100VAC 15VA
240VAC 20VA

24V Power supply specifications
Without option 24VAC 10VA
24VAC 5W
With option 24VAC 15VA
24VAC 10W

Power failure countermeasures:

Storing the setting contents using EEPROM
(Rewrite count Less than one million times)

Terminal screw: M3.5

Insulation resistance:

Between primary terminal and secondary terminal
20MΩ or more (500VDC)

Between primary terminal and grounding terminal
20MΩ or more (500VDC)

Between secondary terminal and grounding terminal
20MΩ or more (500VDC)

Withstand voltage:

Between primary terminal and secondary terminal
1500VAC (For 1 minute)

Between primary terminal and grounding terminal
1500VAC (For 1 minute)

Between secondary terminal and grounding terminal
500VAC (For 1 minute)

※ Primary terminal : Terminal of power supply, control
output, and alarm output

Secondary terminal : All terminals except primary
terminal
power supply (24VAC/24VDC)

Casing: Fire-retardant Polycarbonate

Color: Gray or black

Mounting: Panel mounting

External dimensions: 96(H)x96(W)x127(D)

(Depth from panel screen is 120)

Weight: Without option Approximately 450g
With option Approximately 580g

■ Safety standards

CE approval: EN61326: 1997 +A1+A2+A3

EN61010-1:2001

(Over voltage category II, pollution level 2)

※ Due to the test condition of EMC directive, indication value
or output value which is equivalent to maximum $\pm 10\%$ or
maximum $\pm 2\text{mV}$ which ever is greater, changes.

UL file No. : E214646

UL :UL61010-1 2nd edition

c-UL :CAN/CSA C22.2 No.61010-1-04

■ Reference operation condition

Surrounding temperature: $23^{\circ}\text{C}\pm 2^{\circ}\text{C}$

Surrounding humidity: $55\%\text{RH}\pm 5\%$ (With no condensation)

Power voltage: General power supply specifications
 $100\text{VAC}\pm 1\%$

24V Power supply specifications

$24\text{VDC}\pm 1\%$

Power supply frequency:

General power supply specifications

$50/60\text{Hz}\pm 0.5\%$

24V Power supply specifications

DC

Mounting orientation: Forward or backward $\pm 3^{\circ}$, lateral $\pm 3^{\circ}$

Set up height: Altitude below 2000m

Vibrations: 0m/s^2

Shocks: 0m/s^2

Mounting condition: Simple panel mounting

(There should be a space above below and to the right
and left)

Wind: None

External noise: None

Warm up time: 30 minutes or more

■ Normal operation condition

Surrounding temperature: -10°C to 50°C

(-10°C to 40°C for closed installation)

Surrounding humidity: 10 to $90\%\text{RH}$ (With no condensation)

Power voltage: General power supply specifications
90 to 264VAC

24V Power supply specifications

21.6 to 26.4VDC/AC

Power supply frequency:

General power supply specifications

$50/60\text{Hz}\pm 2\%$

24V Power supply specifications

DC, $50/60\text{Hz}\pm 2\%$

Mounting orientation: Forward or backward $\pm 10^{\circ}$, lateral $\pm 10^{\circ}$

Set up height: Altitude below 2000m

Vibrations: 2m/s^2

Shocks: 0m/s^2

Mounting condition: Simple panel mounting

(There should be a space above below and to the right
and left)

External noise: None

Surrounding temperature variation ratio: Less than $10^{\circ}\text{C}/\text{hour}$

■ Transport conditions

Surrounding temperature: -20°C to 60°C

Surrounding humidity: 5 to 90%RH (With no condensation)

Vibrations: 4.9m/s² (10 to 60Hz)

Shocks: 392m/s²

However these are the factory shipping packing conditions.

■ Storage conditions

Surrounding temperature: -20°C to 60°C

However temperature for long term preservation is

10°C to 30°C.

Surrounding humidity: 5 to 90%RH (With no condensation)

Vibrations: 0m/s²

Shocks: 0m/s²

However these are the factory shipping packing conditions.

■ Option

[Transmission signal output]

Number of outputs: 1

Output signal: 4-20mA (Load resistance Less than 400Ω)

0-1V (Output impedance Approx.10Ω)
(Load resistance More than 50kΩ)

0-10V (Output impedance Approx.10Ω)
(Load resistance More than 50kΩ)

Accuracy rating: ±0.1%FS

Resolution: Approx. 1/30000

Output update period: Approx. 0.1 second

Insulation:

Internal circuit is insulated

(More than 20MΩ and 500VDC)

Transmission signal outputs are also insulated

[Remote signal input]

Number of inputs: 1

Input signal: 4-20mA (Input impedance Approx.50Ω)

0-1V (Input impedance Approx. 500kΩ)

0-10V (Input impedance Approx.100kΩ)

Maximum allowable input:

DC current Less than ±30mA, Less than ±1.5V

DC voltage Less than ±20V

Accuracy rating:±0.1%FS±1digit

Resolution: Approx. 1/30000

Sampling rate: Approx. 0.1 second

Setup switching external input: R/L (Remote/Local)

Insulation: Internal circuit is insulated

(More than 20MΩ and 500VDC)

[Communications Interface]

Communications point: 1

Communications type: RS232C, RS422A, RS485

Protocol: MODBUS(RTU), MODBUS(ASCII), PRIVATE

Setup switching external input: R/L (Remote/Local)

Insulation:

Internal circuit is insulated

(More than 20MΩ and 500VDC)

Communications interfaces are not insulated

[Output 2]

Control period: Approx. 0.1 second

Output type: ON-OFF pulse type, Current output type,

Voltage output type, SSR

SSR drive pulse type. Combinations of these

types are also possible

Insulation:

Internal circuit is insulated

(More than 20MΩ and 500VDC)

Not insulated between outputs

(Only ON-OFF pulse type is insulated)

[External set value switching]

Number of inputs: Maximum 6

Input signal: No-voltage contact, open-collector signal

External contact capacity: 5VDC · 2mA

Function: Execution NO. (SV NO.) selection

(4 points of SV1/SV2/SV4/SV8)

Manual output operation/Automatic output

operation *Option

(2 points of MAN1/AUTO1 and MAN2/AUTO2)

Preset manual/Automatic output operation *Option

Insulation:

Internal circuit is insulated

(More than 20MΩ and 500VDC)

Not insulated between external input points to switch
over the set value

[Panel sealing]

Corresponding to IEC60529 IP54

(Not possible during closed instrumentation)

[Terminal cover]

Cover the terminals for safe.

■ Detailed specifications of accuracy rating

Input type		Accuracy rating	Exceptional specifications
Thermocouple	B	±0.1%FS ±1 digit	0 to 400°C: Out of specifications 400 to 800°C: ±0.2%FS ±1digit
	R, S		0—400°C : ±0.2%FS ±1digit
	N		
	K		-200 to 0°C: ±0.2%FS ±1digit or ±60μV equivalent value, whichever is bigger
	E		-270 to 0°C: ±0.2%FS ±1digit or ±80μV equivalent value, whichever is bigger
	J		-200 to 0°C: ±0.2%FS ±1digit or ±80μV equivalent value, whichever is bigger
	T		-270 to 0°C: ±0.2%FS ±1digit or ±40μV equivalent value, whichever is bigger
	U		-200 to 0°C: ±0.2%FS ±1digit or ±40μV equivalent value, whichever is bigger
	L		-200 to 0°C: ±0.2%FS ±1digit
	WRe5-WRe26		
	W-WRe26		0 to 400°C: ±0.3%FS ±1 digit
	NiMo-Ni		
	Platinel II		
	CR-AuFe		±0.2%FS ±1 digit
PR5-20	0 to 100°C: Out of specifications 100 to 200°C: ±0.5%FS ±1digit		
PtRh40-PtRh20	0 to 400°C: ±1.5%FS ±1digit 400 to 800°C: ±0.8%FS ±1digit		
DC voltage/DC current		±0.1%FS ±1 digit	
Resistance temperature	Pt100 Old Pt100 JPt100	±0.1%FS ±1 digit	Applicable when measurement range is “-100 to 100°C”, -100 to 100°C: ±0.15%FS ±1digit
	JPt50		
	Pt-Co	±0.15%FS ±1 digit	4 to 20K : ±0.5%FS ±1digit 20 to 50K : ±0.3%FS ±1digit

※ It is the measurement range conversion accuracy in reference operating conditions. Reference compensation accuracy is added in case of Thermocouple.

※ K, E, J, T, R, S, B, N: IEC584(1977, 1982), JIS C 1602—1995, JIS C 1605—1995

WRe5-WRe26, W-WRe26, NiMo-Ni, Platinel II, CR-AuFe, PtRh40-PtRh20: ASTM Vol. 14. 03

U, L: DIN43710—1985

Pt 100Ω: IEC751(1995), JIS C 1604—1997

Old Pt 100Ω: IEC751(1983), JIS C 1604—1989, JIS C 1606—1989

JPt 100Ω: JIS C 1604—1981, JIS C 1606—1986

JPt 50Ω: JIS C 1604—1981

■ Reference compensation accuracy

Thermocouple type	Ambient temperature: 23°C±10°C	Ambient temperature: Range other than mentioned on left
K, E, J, T, N, Platinel II	±0.5°C Or ±20μV equivalent value, whichever is more	±1.5°C Or ±60μV equivalent value, whichever is more
Other than mentioned above	±1.0°C Or ±40μV equivalent value, whichever is more	±3.0°C Or ±120μV equivalent value, whichever is more

※ It is the compensation accuracy considered when measurement input value in 0°C. In case of measurement value other than 0°C, above-mentioned electromotive force conversion equivalent value is considered as the compensation accuracy.

17. Parameter list

[Parameters not linked to Execution No.]


Mode No.	Setting Item	Default value (During default settings)	Customer setting value	Setting range	
0	Running SV	0000.0		Measurement scope, linear scale	
	Running PID	P	005.0%	000.0 to 999.9 (0 is two-position control)	
		I	0060s	0000 to 9999 (0 is ∞)	
		D	0030s	0000 to 9999 (0 is OFF)	
	Running alarm 1 and alarm 2	AL1	3000.0		-1999.9 to 3000.0
		AL2	-1999.9		
	Running alarm 3 and alarm 4	AL3	3000.0		
AL4		-1999.9			
1	Alarm cancellation	NON		NON, RESET	
	Remote/Local switching	LOCAL		LOCAL, REMOTE	
	Select Execution NO.	1		1 to 8	
	Auto tuning	END		END, START	
	Simple function/Multiple function selection	MULTI		SIMPLE, MULTI	
2	SV rate of change	UP	0000.0	0000.0 to 2000.0	
		DW	0000.0	-1999.9 to 0000.0	
		Time	M	H (Hours), M (Minutes) S (Seconds)	
	Remote scale	-200.0 to 1370.0		-1999.9 to 3000.0	
	Remote shift	000.00		-199.99 to 200.00	
	Remote filter	00.0s		00.0 to 99.9	
	Cascade constant	r	1.00		0.00 to 1.00
b		000.0%		-99.9 to 100.0	
3	Output dead band	0.5%		0.1 to 9.9	
	Second output PID	P	005.0%	000.0 to 999.9 (0 is two-position control)	
		I	0060s	0000 to 9999 (0 is ∞)	
		D	0030s	0000 to 9999 (0 is OFF)	
	Second output gap	000.0%		-100.0 to 100.0	
	Second output dead band	0.5%		0.1 to 9.9	
	Alarm mode from Alarm1 to Alarm 4	AL1	DH		DH, DHW
		AL2	DL		DL, DLW
		AL3	DH		AH, AHW
		AL4	DL		AL, ALW
	Alarm dead band	AL1	002.00		000.00 to 200.00
		AL2	002.00		
		AL3	002.00		
AL4		002.00			
A.R.W.	L	-050.0%		-100.0 to 000.0	
	H	050.0%		000.0 to 100.0	
Control Algorithm	POSITION		POSITION, VELOCITY		


Mode No.	Setting Item	Default value (During default settings)	Customer setting value	Setting range	
4	Pulse cycle	030s		000 to 180	
	Second output pulse cycle	030s		000 to 180	
	FB tuning	END		END, START	
	FB zero span	Z	00.0%		00.0 to 99.9
		S	100.0%		000.1 to 100.0
	FB dead band	1.0%		0.5 to 5.0	
	Output during PV error	OVR	000.0%		-05.0 to 105.0
		UVR	000.0%		
	Output preset		050.0%		-100.0 to 100.0
	Second output limiter (or second output scale)	L	000.0%		-05.0 to 100.0
		H	100.0%		000.0 to 105.0
	Direct/Reverse control		REVERSE		DIRECT, REVERSE
	Direct/Reverse control for output 2		DIRECT		DIRECT, REVERSE
Preset manual		000.0%		-005.0 to 105.0	
Second output preset manual		000.0%		-0050 to 105.0	
5	Measurement range	Universal	K1	Refer "Measurement range list"	
		4-wire resistance thermometer	Pt100Ω1	Refer "Measurement range list"	
	Unit		°C		°C, K
	RJ		INT		INT, EXT
	Digital filter		00.1s		00.0 to 99.9
	Sensor correction		000.00		-199.9 to 200.0
	PV decimal		1		0 to 4
	Measurement range		-200.0 to 1370.0		Measurement range scale
	Linear scale	DOT	1		0 to 4
Scale		0000.0 to 2000.0		-1999.9 to 3000.0	
SV decimal point for display		1		0 to 4	
6	Transmission type		P V	PV, SV, MV(MV1, MV2), MFB, RSV	
	Transmission scale		-0200.0 to 1370.0	-1999.9 to 3000.0	
7	Communication speed		9600bps	2400, 4800, 9600, 19200, 38400	
	Instrument Number		01	01 to 99	
	Communications function		COM	COM, REM,TRANS	
	Communications/Transmission type		PV	PV, SV, MV(MV1, MV2), MFB, RSV	
	Communications protocol		MODBUS(RTU)	MODBUS(RTU), MODBUS(ASCII), PRIVATE	
	Communications character		8BIT/NON/STOP 1	7BIT/EVEN/STOP1 - - - 8BIT/ODD/STOP2	
1 1	Display backlight		AUTO	GREEN, ORANGE, AUTO	
	Display contrast		050%	000 to 100	
	Key backlight		AUTO	AUTO, OFF, ON	

[Parameters linked to Execution No.]

Mode No.	Setting item		Initial value (During default settings)	Customer setting value (Execution No.)								Setting range
				1	2	3	4	5	6	7	8	
2	SV		0000.0									Measurement range, linear scale
3	PID	P	005.0%									000.0 to 999.9
		I	0060s									0000 to 9999
		D	0030s									0000 to 9999
	Alarm 1 and alarm 2	AL1	3000.0									-19999 to 30000
		AL2	-1999.9									
	Alarm 3 and alarm 4	AL3	3000.0									
AL4		-1999.9										
4	Output variation limiter	UP	100.0%									0.1 to 100.0
		DOWN	-100.0%									-100.0 to -0.1
	Output limiter (or output scale)	L	000.0%									-005.0 to 100.0
		H	100.0%									000.0 to 105.0

18. Parameter directory list





19. Engineering unit sticker

The controller is supplied with sticker for engineering unit. Fix it in the appropriate position as shown in the upper display as per your convenience.

Then after some time after fixing this sticker, there may be peeling-off of the sticker or degradation of character printing due to adhesion degradation.



Precaution

Unincorporated measurement units that are not decided by the measurement laws are included in this unit seal.

CHINO

CHINO CORPORATION

32-8,KUMANO-CHO,ITABASHI-KU,TOKYO 173-8632

Telephone:81-3-3956-2171

Facsimile:81-3-3956-0915

E-mail: inter@chino.co.jp

